


---

## Luggage area light (Wagon only)

---



The luggage area light switch has three positions:

**ON:** The light stays on continuously.

**DOOR:** The light comes on only when the rear gate is opened.

**OFF:** The light stays off.

When leaving your vehicle, make sure the light is turned off to avoid battery discharge.

---

## Luggage cover (Wagon — if equipped)

---



### **CAUTION**

**Do not place anything on the extended cover.**

The luggage cover is provided for covering the luggage compartment and to protect its contents from direct sunlight. This cover is detachable according to your use.