

Luggage area light (Wagon only)



The luggage area light switch has three positions:

ON: The light stays on continuously.

DOOR: The light comes on only when the rear gate is opened.

OFF: The light stays off.

When leaving your vehicle, make sure the light is turned off to avoid battery discharge.

Luggage cover (Wagon — if equipped)




CAUTION

Do not place anything on the extended cover.


The luggage cover is provided for covering the luggage compartment and to protect its contents from direct sunlight. This cover is detachable according to your use.

■ Using the cover



To extend the cover, pull the end of the cover out, then insert its hooks into the catches. To rewind it, unhook it from the catches and it will rewind automatically.

■ To remove the cover



1. Rewind the cover.
2. To take it off the retainer, lift it out.
3. Store the cover in the luggage area.

■ To install the cover

Insert the both ends of the cover into the retainers.