


4. Schematic



- | | |
|---|---|
| ① ABS control module and hydraulic control unit (ABSCM&H/U) | ⑬ Rear right outlet solenoid valve |
| ② ABS control module area | ⑭ Transmission control module (only AT model) |
| ③ Valve relay | ⑮ Diagnosis connector |
| ④ Motor relay | ⑯ Data link connector |
| ⑤ Motor | ⑰ ABS warning light |
| ⑥ Front left inlet solenoid valve | ⑱ Stop light switch |
| ⑦ Front left outlet solenoid valve | ⑲ Stop light |
| ⑧ Front right inlet solenoid valve | ⑳ G sensor (only AWD model) |
| ⑨ Front right outlet solenoid valve | ㉑ Front left ABS sensor |
| ⑩ Rear left inlet solenoid valve | ㉒ Front right ABS sensor |
| ⑪ Rear left outlet solenoid valve | ㉓ Rear left ABS sensor |
| ⑫ Rear right inlet solenoid valve | ㉔ Rear right ABS sensor |