


2. Horn System S904436

A: SCHEMATIC S904436A21

1. HORN S904436A2101

HORN-01

HORN-01



B68 (BLACK)

1	2
3	4

HORN SYSTEM

B: INSPECTION S904436A10

1. HORN RELAY S904436A1001

Check continuity between terminals (indicated in table below) when terminal No. 4 is connected to battery and terminal No. 3 is grounded.

When current flows.	Between terminals No. 1 and No. 2	Continuity exists.
When current does not flow.	Between terminals No. 1 and No. 2	Continuity does not exist.
	Between terminals No. 3 and No. 4	Continuity exists.

