


TRUNK LID TRIM

Exterior/Interior Trim

27. Trunk Lid Trim S911355

A: REMOVAL S911355A18

Remove clips and detach trunk lid trim (A).



B: INSTALLATION S911355A11

Install in the reverse order of removal.