


30. Trunk Room Mat S911351

A: REMOVAL S911351A18

Draw out trunk room mat, and detach box.



B: INSTALLATION S911351A11

Install in the reverse order of removal.