


11. Front Turn Signal Light Bulb

S914412

A: REMOVAL

S914412A18

- 1) Remove headlight assembly. <Ref. to LI-25 REMOVAL, Headlight Assembly.>
- 2) Turn the socket and remove the bulb.



B: INSTALLATION

S914412A11

Install in the reverse order of removal.