3. Accelerator Control Cable \$107007

A: REMOVAL S107007A18

- 1) Remove accelerator pedal. <Ref to SP(H4)-3 REMOVAL, Accelerator Pedal.>
- 2) Separate accelerator cable and accelerator pedal.

B: INSTALLATION S107007A11

1) Install in the reverse order of removal.

CAUTION:

- If cable clamp is damaged, replace it with a new one.
- Never fail to cover outer cable end with boot.
- Be careful not to kink accelerator cable.
- Do not apply grease to the throttle cable on the engine side.
- 2) Adjustment after pedal installation <Ref. to SP(H4)-4 INSTALLATION, Accelerator Pedal.>

C: INSPECTION S107007A10

- 1) Make sure the inner cable is not twisted or frayed.
- 2) Make sure the outer cable is not cracked.