
23. Heater Duct STO1556

A: REMOVAL S701556A18

- 1) Remove heater unit. <Ref. to AC-25 REMOVAL, Heater Unit.>
- 2) Remove front seat. <Ref. to SE-6 REMOVAL, Front Seat.>
- 3) Remove front side sill cover.
- 4) Pull off floor mat to remove heater duct.



B: INSTALLATION S701556A11

Install in the reverse order of removal.