

# HEATER VENT DUCT


HVAC System (Heater, Ventilator and A/C)

---

## 24. Heater Vent Duct S701557

### A: REMOVAL S701557A18

- 1) Remove instrument panel. <Ref. to EI-37 REMOVAL, Instrument Panel.>
- 2) Remove nine screws.
- 3) Remove heater vent duct.



### B: INSTALLATION S701557A11

Install in the reverse order of removal.