

## 6. Airbag Warning Light Illumination Pattern S002629

### A: INSPECTION S002629A10

Keep the ignition switch ON, and confirm that the airbag warning light remains off approximately 6 seconds after being turned on.

