



8. Cowl Panel S911387

A: REMOVAL S911387A18

- 1) Open hood.
- 2) Remove wiper arm. <Ref. to WW-11, REMOVAL, Front Wiper Arm.>
- 3) Remove front panel seal.



- 4) Loosen clips to remove cowl panel.



B: INSTALLATION S911387A11

Install in the reverse order of removal.