

3. Center Exhaust Pipe S172067

A: REMOVAL S172067A18

After removing the center and front exhaust pipes as one unit, separate them. Refer to the procedure for removing the front exhaust pipe. <Ref. to EX-5, REMOVAL, Front Exhaust Pipe.>

B: INSTALLATION S172067A11

Install the center exhaust pipe and front exhaust pipe as one unit. Refer to the procedure for installing the front exhaust pipe. <Ref. to EX-6, INSTALLATION, Front Exhaust Pipe.>

C: INSPECTION S172067A10

- 1) Make sure there are no exhaust leaks from connections and welds.
- 2) Make sure there are no holes or rusting.