


2. Air Cleaner S174087

A: REMOVAL S174087A18

- 1) Remove bolt (A) which install air cleaner case to stays.
- 2) Remove the clip (B) above the air cleaner case.



- 3) Remove air cleaner element.

B: INSTALLATION S174087A11

Install in the reverse order of removal.

CAUTION:

Fasten with a clip after inserting the lower tab of the case.

C: INSPECTION S174087A10

Replace if excessively damaged or dirty.