

## 1. How to Use This Manual SA02675

### A: HOW TO USE THIS MANUAL

SA02675F69

#### 1. STRUCTURE SA02675F6901

Each section consists of SCT that are broken down into SC that are divided into sections for each component. The specifications, maintenance procedures and other information for the components are included, and diagnostic information has also been added where necessary.

#### 2. INDEX SA02675F6902

The first page has an index with tabs. And at the end of each section is an alphabetical index.

#### 3. COMPONENTS SA02675F6903

For each component, a composition drawing is included.

#### 4. SPECIFICATIONS SA02675F6904

If necessary, specifications are also included

#### 5. INSPECTION SA02675F6905

Inspections are included to be carried out before and after maintenance.

#### 6. MAINTENANCE SA02675F6906

Maintenance instructions are provided for each component. When multiple components comprise one process, refer to the instructions for that process for each component.

#### 7. DIAGNOSIS SA02675F6907

Tables showing a step-by-step process make it easy to conduct diagnosis.

#### 8. WARNING, CAUTION, NOTE SA02675F6910

“**WARNING**” is used to indicate points that must be followed to protect the person doing the work and people in the area from injury.

“**CAUTION**” is used to indicate points that must be followed to protect the vehicle or parts from damage or from secondary physical injury.

“**NOTE**” is used to indicate additional information that can improve the efficiency of doing a process.

#### 9. SI UNITS SA02675F6909

Measurements in these manuals are according to the SI units. Metric and yard/pound measurements are also included.