


## TRANSMISSION MOUNTING

Manual Transmission and Differential

### 4. Transmission Mounting




B2H3144B

(1) Pitching stopper

(2) Cushion rubber

(3) Cross member

MT-15




# TRANSMISSION MOUNTING

Manual Transmission and Differential

---

## MEMO



MT-16

