
14. Rear Vehicle Speed Sensor

S502710

A: REMOVAL S502710A18

When removing the rear vehicle speed sensor, refer to "Front Vehicle Speed Sensor". <Ref. to AT-33, REMOVAL, Front Vehicle Speed Sensor.>

B: INSTALLATION S502710A11

When installing the rear vehicle speed sensor, refer to "Front Vehicle Speed Sensor". <Ref. to AT-35, INSTALLATION, Front Vehicle Speed Sensor.>