


MICROPHONE

OnStar (R)

5. Microphone

A: REMOVAL

- 1) Disconnect the ground cable from battery.
- 2) Remove microphone.



B: INSTALLATION

Install in the reverse order of removal.

OS-7