

## INSPECTION MODE

ABS (DIAGNOSTICS)

### 8. Inspection Mode

#### A: OPERATION

Reproduce the condition under which the problem has occurred as much as possible.

Drive the vehicle at a speed more than 40 km/h (25 MPH) for at least one minute.

ABS-21

Vehicle-id:  
SIE-id::A:Operation