

REAR TONE WHEEL

ABS

7. Rear Tone Wheel

A: REMOVAL

Refer to Rear Drive Shaft, because rear tone wheel is integrated with rear drive shaft.

<Ref. to DS-34, REMOVAL, Rear Drive Shaft.>

B: INSTALLATION

Refer to Rear Drive Shaft, because rear tone wheel is integrated with rear drive shaft.

<Ref. to DS-34, INSTALLATION, Rear Drive Shaft.>

C: INSPECTION

Visually check tone wheels teeth (44 pieces) for cracks or dents. If necessary, replace tone wheel with a new one.

NOTE:

Replace BJ assembly with new one as a single unit if there are any defects found on tone wheel is unitized with BJ assembly of drive shaft.

ABS-20

Vehicle-id:
SIE-id::A:Removal

~