



## **CENTER DIFFERENTIAL**

TRANSFER CASE

## **11.Center Differential**

## A: NOTE

For removal, installation and inspection work, refer to "AT" or "MT" section.

AT model:

<Ref. to AT-105, Center Differential Carrier.>

MT model:

<Ref. to MT-46, Center Differential.>







