



## **FRONT TONE WHEEL**

VDC

## **10.Front Tone Wheel**

## A: NOTE

As front tone wheel is integrated with front drive shaft, refer to "DS section" for removal, installation, and inspection procedures. <Ref. to DS-28, Front Drive Shaft.>





