


4. Air Intake Duct

A: REMOVAL

Remove bolts which install air intake duct on the front side of body.



B: INSTALLATION

Install in the reverse order of removal.

C: INSPECTION

Inspect for cracks and loose connections. Check that no foreign objects are mixed in the air intake duct.