

GENERAL DIAGNOSTIC

CONTROL SYSTEMS

9. General Diagnostic**A: INSPECTION**

Symptom	Problem parts
Shift lock does not function.	<ul style="list-style-type: none">• Stop light switch• Shift lock solenoid• Integrated module
Shift lock cannot be released.	<ul style="list-style-type: none">• Stop light switch• Shift lock solenoid• Integrated module• Inhibitor switch
Key interlock does not function.	<ul style="list-style-type: none">• Key warning switch• "P" position switch• Key lock solenoid• Integrated module
Key interlock cannot be released.	<ul style="list-style-type: none">• Key warning switch• "P" position switch• Key lock solenoid• Integrated module
Starter does not run.	<ul style="list-style-type: none">• Inhibitor switch• Select cable• Starter circuit
Back-up light does not light up.	<ul style="list-style-type: none">• Inhibitor switch• Select cable• Back-up light circuit

CS-42