


HARNESS COMPONENTS LOCATION

WIRING SYSTEM

53.Harness Components Location

A: LOCATION

1. SEDAN MODEL




- | | | |
|-------------------------------------|-------------------------|---------------------------------------|
| (1) Front wiring harness | (6) Rear door cord RH | (11) Rear door cord LH |
| (2) Engine wiring harness | (7) Rear wiring harness | (12) Front door cord LH |
| (3) Bulkhead wiring harness | (8) Roof cord | (13) Transmission cord |
| (4) Instrument panel wiring harness | (9) Fuel tank cord | (14) Rear oxygen sensor cord |
| (5) Front door cord RH | (10) Trunk lid cord | (15) On refueling vapor recovery cord |

HARNESS COMPONENTS LOCATION

WIRING SYSTEM

2. WAGON MODEL




- | | | |
|-------------------------------------|-------------------------|---------------------------------------|
| (1) Front wiring harness | (6) Rear door cord RH | (11) Rear door cord LH |
| (2) Engine wiring harness | (7) Rear wiring harness | (12) Front door cord LH |
| (3) Bulkhead wiring harness | (8) Roof cord | (13) Transmission cord |
| (4) Instrument panel wiring harness | (9) Fuel tank cord | (14) Rear oxygen sensor cord |
| (5) Front door cord RH | (10) Rear gate cord | (15) On refueling vapor recovery cord |

HARNESS COMPONENTS LOCATION

WIRING SYSTEM

3. PICK-UP MODEL



WI-00726

- | | | |
|-------------------------------------|---------------------------------|---------------------------------------|
| (1) Front wiring harness | (6) Rear door cord RH | (11) Rear door cord LH |
| (2) Engine wiring harness | (7) Rear wiring harness (Front) | (12) Front door cord LH |
| (3) Bulkhead wiring harness | (8) Roof cord | (13) Transmission cord |
| (4) Instrument panel wiring harness | (9) Fuel tank cord | (14) Rear oxygen sensor cord |
| (5) Front door cord RH | (10) Rear wiring harness (Rear) | (15) On refueling vapor recovery cord |

WI-219