

31.Fuel Filter

A: SPECIFICATION

Fuel filter forms a single unit with fuel pump.
Refer to "Fuel Pump" for removal and installation.
<Ref. to FU(H4DOTC)-53, REMOVAL, Fuel Pump.>
<Ref. to FU(H4DOTC)-53, INSTALLATION, Fuel Pump.>