

### 27. Fuel Filter

#### A: SPECIFICATION

Fuel filter forms a single unit with fuel pump.

Refer to "Fuel Pump" for removal and installation.

<Ref. to FU(H6DO)-49, REMOVAL, Fuel Pump.>

<Ref. to FU(H6DO)-49, INSTALLATION, Fuel Pump.>