## **Clear Memory Mode**

**AUTOMATIC TRANSMISSION (DIAGNOSTICS)** 

## 9. Clear Memory Mode

## **A: OPERATION**

Refer to "Subaru Select Monitor" for information about how to clear a DTC. <Ref. to 4AT(diag)-16, CLEAR MEMORY MODE, OPERATION, Subaru Select Monitor.>