

12. Transfer Clutch Pressure Test

A: NOTE

For inspection, refer to "4AT" or "5AT" section.

4AT model:

<Ref. to 4AT-34, Transfer Clutch Pressure Test.>

5AT model:

<Ref. to 5AT-33, Transfer Clutch Pressure Test.>

Transfer Clutch Pressure Test

TRANSFER CASE

DRIVE SHAFT SYSTEM

DS

	Page
1. General Description	2
2. Propeller Shaft	10
3. Front Axle	13
4. Front Hub Unit Bearing	17
5. Rear Hub Unit Bearing	19
6. Front Drive Shaft	22
7. Rear Drive Shaft	26
8. General Diagnostic Table	30