

## 61.Rear Wiring Harness and Rear Gate Cord

## A: LOCATION

Connector				Connecting to	
No.	Pole	Color	Area	No.	Description
R15	8	★	C-1	R213	Fuel cord 1
R22	3	★	C-1		Rear door switch LH
R26	4	★	C-4		Rear combination light RH
R28	4	★	C-3		Rear combination light LH
R32	2	★	C-2		Luggage room power supply
R37	3	★	C-4	D33	Rear gate cord
R38	8	★	C-5	D34	
R39	10	★	C-5	D35	
R46	6	★	D-1	R67	Fuel cord 2
R47	3	Black	C-4		Fuel tank pressure sensor
R58	6	Gray	D-2		Fuel pump assembly
R59	2	★	D-2		Fuel gauge sub unit
R67	6	★	D-2	R46	Rear wiring harness
R68	2	Dark gray	D-3		Pressure control solenoid valve
R79	6	★	B-2		Trailer connector
R97	1	★	B-2		Antenna amplifier
R117	2	★	C-3		Woofers
R122	10	Black	C-2		Fuel pump control unit
R143	2	Gray	C-4		Fuel tank sensor control valve
R213	8	★	C-1	R15	Rear wiring harness

★ : White or natural color

Connector				Connecting to	
No.	Pole	Color	Area	No.	Description
D33	3	★	C-4	R37	Rear wiring harness
D34	8	★	C-4	R38	
D35	10	★	C-5	R39	
D37	3	★	B-3		Luggage room light
D39	2	★	B-3		High-mounted stop light
D43	4	★	B-4		Rear wiper motor
D44	2	★	A-5		License plate light
D46	2	Black	A-4		Rear gate latch switch
D47	2	Gray	A-5		Rear gate lock actuator
D48	1	Black	B-3		Rear defogger
D87	2	★	A-5		Back-up light RH
D89	1	★	B-4		Noise filter
D91	2	★	A-4		Back-up light LH

★ : White or natural color

