





62. Harness Repair Kit






A: SPECIFICATION

1. ADAPTATION TABLE

Connector No.	Adaptive repair kit	Terminal No.	Harness repair kit No.
B3	 <p style="text-align: right;">WI-04674</p>	3	TFA-042
B6	 <p style="text-align: right;">WI-04675</p>	ALL	TFA-021
B8	 <p style="text-align: right;">WI-04676</p>	ALL	TFA-033
B11	 <p style="text-align: right;">WI-04677</p>	ALL	TFA-036






Harness Repair Kit

WIRING SYSTEM

Connector No.	Adaptive repair kit	Terminal No.	Harness repair kit No.
<p>B12 (2.5 L non-turbo and 2.5 L non-turbo (U5) model)</p>	 <p style="text-align: right;">WI-11984</p>	1 — 12	TFA-018
B15	 <p style="text-align: right;">WI-04675</p>	ALL	TFA-021
<p>B19 (2.5 L turbo model)</p>	 <p style="text-align: right;">WI-04682</p>	1, 2	TFA-029
<p>B54 (4AT model)</p>	 <p style="text-align: right;">WI-11985</p>	1 — 24	TFA-016
<p>B54 (5AT model)</p>	 <p style="text-align: right;">WI-04684</p>	ALL	TFA-016

Harness Repair Kit

WIRING SYSTEM

Connector No.	Adaptive repair kit	Terminal No.	Harness repair kit No.
B55 (4AT model)	 <p style="text-align: right;">WI-11986</p>	1 — 31	TFA-016
B55 (5AT model)	 <p style="text-align: right;">WI-11987</p>	1 — 24	TFA-016
B128	 <p style="text-align: right;">WI-11988</p>	ALL	TFA-018
B134 (2.5 L non-turbo and 2.5 L non-turbo (U5) model)	 <p style="text-align: right;">WI-11989</p>	1 — 5, 7	TFA-011
		8 — 17, 20 — 27, 30 — 34	TFA-013
		18, 19, 28, 29	TFA-014
		6	TFA-016
B134 (3.0 L model)	 <p style="text-align: right;">WI-11989</p>	1 — 5, 7	TFA-011
		8 — 17, 20 — 27, 30 — 34	TFA-013
		18, 19, 28, 29	TFA-014
		6	TFA-016







Harness Repair Kit

WIRING SYSTEM

Connector No.	Adaptive repair kit	Terminal No.	Harness repair kit No.
B134 (2.5 L turbo model)	<p style="text-align: right;">WI-11990</p>	2 — 7	TFA-011
		8 — 34	TFA-013
		1	TFA-016
B135 (2.5 L non-turbo and 2.5 L non-turbo (U5) model)	<p style="text-align: right;">WI-11991</p>	2, 3, 6, 7	TFA-011
		8 — 20, 24 — 28, 32 — 35	TFA-013
		21 — 23, 29 — 31	TFA-014
		1, 4, 6	TFA-016
B135 (3.0 L model)	<p style="text-align: right;">WI-11991</p>	2, 3, 6, 7	TFA-011
		8 — 20, 24 — 28, 32 — 35	TFA-013
		21 — 23, 29 — 31	TFA-014
		1, 4, 5	TFA-016
B135 (2.5 L turbo model)	<p style="text-align: right;">WI-11992</p>	1, 3 — 7	TFA-011
		8 — 35	TFA-013
		2	TFA-016
B136 (2.5 L non-turbo and 2.5 L non-turbo (U5) model)	<p style="text-align: right;">WI-11993</p>	1 — 6	TFA-011
		7 — 35	TFA-013






Harness Repair Kit

WIRING SYSTEM

Connector No.	Adaptive repair kit	Terminal No.	Harness repair kit No.
B136 (3.0 L model)	 <p>WI-11993</p>	1 — 6	TFA-011
		7 — 35	TFA-013
B136 (2.5 L turbo model)	 <p>WI-11994</p>	1 — 6	TFA-011
		7 — 14, 16, 19 — 27, 30 — 33, 35	TFA-013
B137 (3.0 L model)	 <p>WI-11995</p>	1, 5 — 7	TFA-011
		8 — 31	TFA-013
B137 (2.5 L non-turbo and 2.5 L non-turbo (U5) model)	 <p>WI-11996</p>	6	TFA-016
		1 — 7	TFA-011
B137 (2.5 L turbo model)	 <p>WI-11996</p>	8 — 31	TFA-013
B230 (3.0 L model)		ALL	TFA-021
	 <p>WI-04700</p>		






Harness Repair Kit

WIRING SYSTEM

Connector No.	Adaptive repair kit	Terminal No.	Harness repair kit No.
B280	 <p style="text-align: right;">WI-11997</p>	1, 2, 8, 9, 21, 22	TFA-023
		3 — 7, 10 — 20, 23 — 30	TFA-025
B281	 <p style="text-align: right;">WI-11998</p>	1, 2, 8, 9, 20, 21	TFA-023
		3 — 28	TFA-025
B292	 <p style="text-align: right;">WI-04703</p>	ALL	TFA-012
B315	 <p style="text-align: right;">WI-07643</p>	ALL	TFA-042
B348 (3.0 L model)	 <p style="text-align: right;">WI-07644</p>	ALL	TFA-021






Harness Repair Kit

WIRING SYSTEM

Connector No.	Adaptive repair kit	Terminal No.	Harness repair kit No.
B350	 <p style="text-align: right;">WI-04705</p>	ALL	TFA-016
B351	 <p style="text-align: right;">WI-04707</p>	ALL	TFA-012
B359	 <p style="text-align: right;">WI-04708</p>	1	TFA-026
		2, 3	TFA-033
B391 (2.5 L turbo model)	 <p style="text-align: right;">WI-06096</p>	ALL	TFA-018
j6	 <p style="text-align: right;">WI-07648</p>	8 — 16	TFA-016

Harness Repair Kit

WIRING SYSTEM

Connector No.	Adaptive repair kit	Terminal No.	Harness repair kit No.
j26	 <p style="text-align: right;">WI-04712</p>	1 — 5, 7 — 10, 12 — 14	TFA-012
j59	 <p style="text-align: right;">WI-07650</p>	1, 5, 6, 8, 9	TFA-016
j79	 <p style="text-align: right;">WI-04715</p>	ALL	TFA-016
j84	 <p style="text-align: right;">WI-07652</p>	1, 2, 4, 5, 7 — 10, 12, 14, 15, 17 — 34	TFA-025
R122 (3.0 L and 2.5 L turbo model)	 <p style="text-align: right;">WI-07654</p>	5 — 10	TFA-030