



Starter System

WIRING SYSTEM

8. Starter System

A: WIRING DIAGRAM

1. 2.5 L NON-TURBO MODEL



WI-11922


Starter System

WIRING SYSTEM

2. 2.5L TURBO MODEL AND 3.0 L MODEL

ST(EUL)-01

ST(EUL)-01



WI-11923