













## 2. Performance Test Diagnosis




In various conditions caused to other air conditioning system, the characteristics revealed on manifold gauge reading are shown in the following.

As to the method of a performance test, refer to the item of "Performance Test".

Each shaded area on the following tables indicates a reading of the normal system when the temperature of outside air is 32.5°C (91°F).

Condition	Probable cause	Corrective action
<p data-bbox="115 417 570 443">INSUFFICIENT REFRIGERANT CHARGE</p> <div data-bbox="185 474 594 764"> <p data-bbox="185 510 324 562">Low-pressure gauge</p> <p data-bbox="451 510 594 562">High-pressure gauge</p> </div> <p data-bbox="594 806 675 827">G4M0673</p>	<p data-bbox="699 417 906 443">Insufficient cooling.</p> <p data-bbox="979 417 1192 470">Refrigerant is small, or leaking a little.</p>	<p data-bbox="1230 417 1427 590">1. Leak test. 2. Repair leak. 3. Charge system. Evacuate, as necessary, and recharge system.</p>
<p data-bbox="115 837 435 863">ALMOST NO REFRIGERANT</p> <div data-bbox="185 894 594 1184"> <p data-bbox="185 930 324 982">Low-pressure gauge</p> <p data-bbox="451 930 594 982">High-pressure gauge</p> </div> <p data-bbox="594 1226 675 1247">G4M0674</p>	<p data-bbox="699 837 889 863">No cooling action.</p> <p data-bbox="979 837 1175 890">Serious refrigerant leak.</p>	<p data-bbox="1230 837 1459 1123">Stop compressor immediately. 1. Leak test. 2. Discharge system. 3. Repair leak(s). 4. Replace receiver drier if necessary. 5. Check oil level. 6. Evacuate and recharge system.</p>
<p data-bbox="115 1257 431 1283">FAULTY EXPANSION VALVE</p> <div data-bbox="185 1335 594 1625"> <p data-bbox="185 1371 324 1423">Low-pressure gauge</p> <p data-bbox="451 1371 594 1423">High-pressure gauge</p> </div> <p data-bbox="594 1667 675 1688">G4M0675</p>	<p data-bbox="699 1257 932 1341">Slight cooling. Sweating or frosted expansion valve inlet.</p> <p data-bbox="979 1257 1175 1341">Expansion valve restricts refrigerant flow.</p> <ul data-bbox="979 1346 1208 1545" style="list-style-type: none"> <li>● Expansion valve is clogged.</li> <li>● Expansion valve is inoperative.</li> <li>● Valve stuck closed.</li> </ul> <p data-bbox="979 1486 1208 1545">Thermal bulb has lost charge.</p>	<ul data-bbox="1230 1257 1463 1661" style="list-style-type: none"> <li>● If valve inlet reveals sweat or frost: 1. Discharge system. 2. Remove valve and clean it. Replace it if necessary.</li> <li>3. Evacuate system.</li> <li>4. Charge system.</li> <li>● If valve does not operate: 1. Discharge system. 2. Replace valve. 3. Evacuate and charge system.</li> </ul>

Condition		Probable cause	Corrective action
<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p>Low-pressure gauge</p>  </div> <div style="text-align: center;"> <p>High-pressure gauge</p>  </div> </div>  <p style="text-align: right;">G4M0676</p>	<p>Insufficient cooling. Sweated suction line. No cooling. Sweating or frosted suction line.</p>	<p>Expansion valve allows too much refrigerant through evaporator. Faulty seal of O-ring in expansion valve.</p>	<p>Check valve for operation. If suction side does not show a pressure decrease, replace valve. 1. Discharge system. 2. Remove expansion valve and replace O-ring. 3. Evacuate and replace system.</p>
<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p>Low-pressure gauge</p>  </div> <div style="text-align: center;"> <p>High-pressure gauge</p>  </div> </div>  <p style="text-align: right;">G4M0677</p>	<p>Insufficient cooling.</p>	<p>Air mixed with refrigerant in system.</p>	<p>1. Discharge system. 2. Replace receiver drier. 3. Evacuate and charge system.</p>
<p><b>AIR IN SYSTEM</b></p>	<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p>Low-pressure gauge</p>  </div> <div style="text-align: center;"> <p>High-pressure gauge</p>  </div> </div>  <p style="text-align: right;">G4M0678</p>	<p>After operation for a while, pressure on suction side may show vacuum pressure reading. During this condition, discharge air will be warm. As warning of this, reading shows 39 kPa (0.4 kg/cm<sup>2</sup>, 6 psi) vibration.</p>	<p>Drier is saturated with moisture. Moisture has frozen at expansion valve. Refrigerant flow is restricted.</p>
<p><b>MOISTURE IN SYSTEM</b></p>	<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p>Low-pressure gauge</p>  </div> <div style="text-align: center;"> <p>High-pressure gauge</p>  </div> </div>  <p style="text-align: right;">G4M0679</p>	<p>1. Discharge system. 2. Replace receiver drier (twice if necessary). 3. Evacuate system completely. (Repeat 30 minute evacuating three times.) 4. Recharge system.</p>	

Condition	Probable cause	Corrective action
<p><b>FAULTY CONDENSER</b></p>  <p>Low-pressure gauge</p> <p>High-pressure gauge</p> <p>G4M0680</p>	<p>No cooling action. Engine may overheat. Suction line is very hot.</p>	<p>Condenser is often found not functioning well.</p> <ul style="list-style-type: none"> <li>● Check condenser cooling fan.</li> <li>● Check condenser for dirt accumulation.</li> <li>● Check engine cooling system for overheat.</li> <li>● Check for refrigerant overcharge.</li> <li>● If pressure remains high in spite of all above actions taken, remove and inspect the condenser for possible oil clogging.</li> </ul>
<p><b>HIGH-PRESSURE LINE BLOCKED</b></p>  <p>Low-pressure gauge</p> <p>High-pressure gauge</p> <p>G4M0681</p>	<p>Insufficient cooling. Frosted high-pressure liquid line.</p>	<p>Drier clogged, or restriction in high-pressure line.</p> <ol style="list-style-type: none"> <li>1. Discharge system.</li> <li>2. Remove receiver drier or strainer and replace it.</li> <li>3. Evacuate and charge system.</li> </ol>
<p><b>FAULTY COMPRESSOR</b></p>  <p>Low-pressure gauge</p> <p>High-pressure gauge</p> <p>G4M0682</p>	<p>Insufficient cooling.</p>	<p>Internal problem in compressor, or damaged gasket and valve.</p> <ol style="list-style-type: none"> <li>1. Discharge system.</li> <li>2. Remove and check compressor.</li> <li>3. Repair or replace compressor.</li> <li>4. Check oil level.</li> <li>5. Replace receiver drier.</li> <li>6. Evacuate and charge system.</li> </ol>