


# 1. General Description







## A: WIRING DIAGRAM

The wiring diagram of each system is illustrated so that you can understand the path through which the electric current flows from the battery. Sketches and codes are used in the diagrams. They should read as follows:

- Each connector and its terminal position are indicated by a sketch of the connector in a disconnected state which is viewed from the front, as shown in figure.

- The number of poles or pins, presence of a lock, and pin number of each terminal are indicated in the sketch of each connector. In the sketch, the highest pole number refers to the number of poles which the connector has. For example, the sketch of the connector shown in figure indicates the connector has 9 poles.




Connector used in vehicle	Connector shown in wiring diagram		
	Sketch	Symbol	Number of poles
 <p>G6M0194</p>	<p>Double frames Indicates a lock is included.</p>  <p>Indicates the number of poles.</p> <p>G6M0196</p>		<p>Numbered in order from upper right to lower left.</p>
 <p>G6M0195</p>	<p>Indicates a lock is included.</p>  <p>Single frame</p> <p>G6M0197</p>	 <p>G6M0198</p>	<p>Numbered in order from upper left to lower right.</p>

# WIRING DIAGRAM

[D1A0] 6-3

## 1. General Description


- When one set of connectors is viewed from the front side, the pole numbers of one connector are symmetrical to those of the other. When these two connectors are connected as a unit, the poles which have the same number are joined.




- Electrical wiring harness:**  
The connectors are numbered along with the number of poles, external colors, and mating connections in the accompanying list.
- The sketch of each connector in the wiring diagram usually shows the "A" side of the connector. The relationship between the wire color, terminal number and connector is described in figure.

**NOTE:**

A wire which runs in one direction from a connector terminal sometimes may have a different color from that which runs in the other direction from that terminal.




- In wiring diagram, connectors which have no terminal number refer to one-pole types. Sketches of these connectors are omitted intentionally.



- The following color codes are used to indicate the colors of the wires used.

Color code	Color
L	Blue
B	Black
Y	Yellow
G	Green
R	Red
W	White
Br	Brown
Lg	Light green
Gr	Gray
P	Pink
Or	Orange
Lb	Light Blue
V	Violet
SA	Sealed (Inner)
SB	Sealed (Outer)




## 6-3 [D1A0]

### 1. General Description

## WIRING DIAGRAM

- The wire color code, which consists of two letters (or three letters including Br or Lg), indicates the standard color (base color of the wire covering) by its first letter and the stripe marking by its second letter.



- The table lists the nominal sectional areas and allowable currents of the wires.

Nominal sectional area mm <sup>2</sup>	No. of strands/ strand diameter	Outside diameter of finished wiring mm	Allowable current Amps/40°C
0.3	7/0.26	1.8	7
0.5	7/0.32	2.2 (or 2.0)	12
0.75	30/0.18	2.6 (or 2.4)	16
0.85	11/0.32	2.4 (or 2.2)	16
1.25	16/0.32	2.7 (or 2.5)	21
2	26/0.32	3.1 (or 2.9)	28
3	41/0.32	3.8 (or 3.6)	38
5	65/0.32	4.6 (or 4.4)	51
8	50/0.45	5.5	67

#### CAUTION:


When replacing or repairing a wire, be sure to use the same size and type of the wire which was originally used.

#### NOTE:

- The allowable current in the above table indicates the tolerable amperage of each wire at an ambient temperature of 40°C (104°F).

- The allowable current changes with ambient temperature. Also, it changes if a bundle of more than two wires is used.


- Each unit is directly grounded to the body or indirectly grounds through a harness ground terminal. Different symbols are used in the wiring diagram to identify the two grounding systems.



- The ground points shown in the wiring diagram refer to the following:

#### NOTE:


All wiring harnesses are provided with a ground point which should be securely connected.



- Relays are classified as normally-open or normally-closed.

The normally-closed relay has one or more contacts. The wiring diagram shows the relay mode when the energizing circuit is OFF.

# WIRING DIAGRAM




Key to symbols:

- —▶ : Current flows.
- × —▶ : Current does not flow.



- Each connector number shown in the wiring diagram corresponds to that in the wiring harness. The location of each connector in the actual vehicle is determined by reading the first character of the connector (for example, a “F” for F8, “I” for I16, etc.) and the type of wiring harness. The first character of each connector number refers to the area or system of the vehicle.

Symbol	Wiring harness and Cord
F	Front wiring harness
B	Bulkhead wiring harness
E	Engine wiring harness
T	Transmission cord
D	Door cord LH & RH, Rear gate cord
I	Instrument panel wiring harness
R	Rear wiring harness, Rear defogger cord Room light cord, Fuel tank cord, Sunroof cord, Trunk lid cord
P	Floor wiring harness



## 2. Basic Diagnostics Procedures

### A: BASIC PROCEDURE

#### 1. GENERAL

The most important purpose of diagnostics is to determine which part is malfunctioning quickly, to save time and labor.

#### 2. IDENTIFICATION OF TROUBLE SYMPTOM

Determine what the problem is based on the symptom.

#### 3. PROBABLE CAUSE OF TROUBLE

Look at the wiring diagram and check the system's circuit. Then check the switch, relay, fuse, ground, etc.

#### 4. LOCATION AND REPAIR OF TROUBLE

- 1) Using the diagnostics narrow down the causes.
- 2) If necessary, use a voltmeter, ohmmeter, etc.
- 3) Before replacing certain component parts (switch, relay, etc.), check the power supply, ground, for open wiring harness, poor connectors, etc. If no problems are encountered, check the component parts.

#### 5. CONFIRMATION OF SYSTEM OPERATION

After repairing, ensure that the system operates properly.


### B: INSPECTION

#### 1. VOLTAGE MEASUREMENT

- 1) Using a voltmeter, connect the negative lead to a good ground point or negative battery terminal and the positive lead to the connector or component terminal.
- 2) Contact the positive probe of the voltmeter on connector (A). The voltmeter will indicate a voltage.

- Each connector number shown in the wiring diagram corresponds to that in the wiring harness. The location of each connector in the actual vehicle is determined by reading the first character of the connector (for example, a “F” for F8, “I” for I16, etc.) and the type of wiring harness. The first character of each connector number refers to the area or system of the vehicle.

Symbol	Wiring harness and Cord
F	Front wiring harness
B	Bulkhead wiring harness
E	Engine wiring harness
T	Transmission cord
D	Door cord LH & RH, Rear gate cord
I	Instrument panel wiring harness
R	Rear wiring harness, Rear defogger cord Room light cord, Fuel tank cord, Sunroof cord, Trunk lid cord
P	Floor wiring harness



## 2. Basic Diagnostics Procedures

### A: BASIC PROCEDURE

#### 1. GENERAL

The most important purpose of diagnostics is to determine which part is malfunctioning quickly, to save time and labor.

#### 2. IDENTIFICATION OF TROUBLE SYMPTOM

Determine what the problem is based on the symptom.

#### 3. PROBABLE CAUSE OF TROUBLE

Look at the wiring diagram and check the system’s circuit. Then check the switch, relay, fuse, ground, etc.

#### 4. LOCATION AND REPAIR OF TROUBLE

- 1) Using the diagnostics narrow down the causes.
- 2) If necessary, use a voltmeter, ohmmeter, etc.
- 3) Before replacing certain component parts (switch, relay, etc.), check the power supply, ground, for open wiring harness, poor connectors, etc. If no problems are encountered, check the component parts.

#### 5. CONFIRMATION OF SYSTEM OPERATION


After repairing, ensure that the system operates properly.

### B: INSPECTION

#### 1. VOLTAGE MEASUREMENT

- 1) Using a voltmeter, connect the negative lead to a good ground point or negative battery terminal and the positive lead to the connector or component terminal.
- 2) Contact the positive probe of the voltmeter on connector (A). The voltmeter will indicate a voltage.

3) Shift the positive probe to connector (B). The voltmeter will indicate no voltage.



4) With test set-up held as it is, turn switch ON. The voltmeter will indicate a voltage and, at the same time, the light will come on.

5) The circuit is in good order. If a problem such as a lamp failing to light occurs, use the procedures outlined above to track down the malfunction.


## 2. CIRCUIT CONTINUITY CHECKS

1) Disconnect the battery terminal or connector so there is no voltage between the check points. Contact the two leads of an ohmmeter to each of the check points.

If the circuit has diodes, reverse the two leads and check again.

2) Use an ohmmeter to check for diode continuity. When contacting the negative lead to the diode positive side and the positive lead to the negative side, there should be continuity.

When contacting the two leads in reverse, there should be no continuity.




3) Symbol “○-○” indicates that continuity exists between two points or terminals. For example, when a switch position is “3”, continuity exists among terminals 1, 3 and 6, as shown in table.

Terminal	1	2	3	4	5	6
Switch Position						
OFF						
1	○				○	○
2	○			○		○
3	○		○			○
4	○	○				○

## 3. HOW TO DETERMINE AN OPEN CIRCUIT


1) Voltmeter method:

An open circuit is determined by measuring the voltage between respective connectors and ground using a voltmeter, starting with the connector closest to the power supply. The power supply must be turned ON so that current flows in the circuit. If voltage is not present between a particular connector and ground, the circuit between that connector and the previous connector is open.



2) Ohmmeter method:


Disconnect all connectors affected, and check continuity in the wiring between adjacent connectors. When the ohmmeter indicates “infinite”, the wiring is open.



#### 4. HOW TO DETERMINE A SHORT-CIRCUIT


##### 1) Test lamp method:

Connect a test lamp (rated at approximately 3 watts) in place of the blown fuse and allow current to flow through the circuit. Disconnect one connector at a time from the circuit, starting with the one located farthest from the power supply. If the test lamp goes out when a connector is disconnected, the wiring between that connection and the next connector (farther from the power supply) is shorted.



##### 2) Ohmmeter method:

Disconnect all affected connectors, and check continuity between each connector and ground. When ohmmeter indicates continuity between a particular connector and ground, that connector is shorted.




### 3. Working Precautions

#### A: PRECAUTIONS WHEN WORKING WITH THE PARTS MOUNTED ON THE VEHICLE

- 1) When working under a vehicle which is jacked-up, always be sure to use safety stands.
- 2) The parking brake must always be applied during working. Also, in automatic transmission vehicles, keep the select lever set to the P (Parking) range.
- 3) Be sure the workshop is properly ventilated when running the engine. Further, be careful not to touch the belt or fan while the engine is operating.
- 4) Be careful not to touch hot metal parts, especially the radiator and exhaust system immediately after the engine has been shut off.

#### B: PRECAUTIONS IN TROUBLE DIAGNOSIS AND REPAIR OF ELECTRIC PARTS


- 1) The battery cable must be disconnected from the battery's (-) terminal, and the ignition switch must be set to the OFF position, unless otherwise required by the diagnostics.
- 2) Securely fasten the wiring harness with clamps and slips so that the harness does not interfere with the body end parts or edges and bolts or screws.
- 3) When installing parts, be careful not to catch them on the wiring harness.
- 4) When disconnecting a connector, do not pull the wires, but pull while holding the connector body.



#### 4. HOW TO DETERMINE A SHORT-CIRCUIT


##### 1) Test lamp method:

Connect a test lamp (rated at approximately 3 watts) in place of the blown fuse and allow current to flow through the circuit. Disconnect one connector at a time from the circuit, starting with the one located farthest from the power supply. If the test lamp goes out when a connector is disconnected, the wiring between that connection and the next connector (farther from the power supply) is shorted.



##### 2) Ohmmeter method:

Disconnect all affected connectors, and check continuity between each connector and ground. When ohmmeter indicates continuity between a particular connector and ground, that connector is shorted.




### 3. Working Precautions

#### A: PRECAUTIONS WHEN WORKING WITH THE PARTS MOUNTED ON THE VEHICLE


- 1) When working under a vehicle which is jacked-up, always be sure to use safety stands.
- 2) The parking brake must always be applied during working. Also, in automatic transmission vehicles, keep the select lever set to the P (Parking) range.
- 3) Be sure the workshop is properly ventilated when running the engine. Further, be careful not to touch the belt or fan while the engine is operating.
- 4) Be careful not to touch hot metal parts, especially the radiator and exhaust system immediately after the engine has been shut off.

#### B: PRECAUTIONS IN TROUBLE DIAGNOSIS AND REPAIR OF ELECTRIC PARTS

- 1) The battery cable must be disconnected from the battery's (-) terminal, and the ignition switch must be set to the OFF position, unless otherwise required by the diagnostics.
- 2) Securely fasten the wiring harness with clamps and slips so that the harness does not interfere with the body end parts or edges and bolts or screws.
- 3) When installing parts, be careful not to catch them on the wiring harness.
- 4) When disconnecting a connector, do not pull the wires, but pull while holding the connector body.




5) Some connectors are provided with a lock. One type of such a connector is disconnected by pushing the lock, and the other, by moving the lock up. In either type the lock shape must be identified before attempting to disconnect the connector. To connect, insert the connector until it snaps and confirm that it is tightly connected.



6) When checking continuity between connector terminals, or measuring voltage across the terminal and ground, always contact tester probe(s) on terminals from the wiring connection side. If the probe is too thick to gain access to the terminal, use "mini" test leads.

To check water-proof connectors (which are not accessible from the wiring side), contact test probes on the terminal side being careful not to bend or damage the terminals.




7) Sensors, relays, electrical unit, etc., are sensitive to strong impacts.

Handle them with care so that they are not dropped or mishandled.



### 4. How to Use Wiring Diagram



**A: RELAY**

A symbol used to indicate a relay.

**B: CONNECTOR-1**

The sketch of the connector indicates the one-pole types.

**C: WIRING CONNECTION**

Some wiring diagrams are indicated in foldouts for convenience. Wiring destinations are indicated where necessary by corresponding symbols (as when two pages are needed for clear indication).

**D: FUSE No. & RATING**

The "FUSE No. & RATING" corresponds that used in the fuse box (main fuse box, and joint box).

**E: CONNECTOR-2**

- Each connector is indicated by a symbol.
- Each terminal number is indicated in the corresponding wiring diagram in an abbreviated form.
- For example, terminal number "C2" refers to No. 2 terminal of connector (C: F41) shown in the connector sketch.

**F: CONNECTOR SKETCH**

- Each connector sketch clearly identifies the shape and color of a connector as well as terminal locations. Non-colored connectors are indicated in natural color.
- When more than two types of connector number are indicated in a connector sketch, it means that the same type connectors are used.

**G: GROUND**

Each grounding point can be located easily by referring to the corresponding wiring harness.

**H: DIODE**


A symbol is used to indicate a diode.

**I: WIRE TRACING ON EXTENDED WIRING DIAGRAMS**

For a wiring diagram extending over at least two pages, a symbol (consisting of the same characters with arrows), as shown below, facilitates wire tracing from one page to the next.

A ↔ A, B ↔ B

**J: SYMBOLS OF WIRE CONNECTION AND CROSSING**



**K: POWER SUPPLY ROUTING**

A symbol is used to indicate the power supply in each wiring diagram.

“MB-5”, “MB-6”, etc., which are used as power supply symbols throughout the text, correspond with those shown in the POWER SUPPLY ROUTING in the wiring diagram.

Accordingly, using the POWER SUPPLY ROUTING and wiring diagrams permits service personnel to understand the entire electrical arrangement of a system.

**L: S.M.J.**

A symbol is used to indicate the terminal arrangement of the super multiple junction. The S.M.J. is not shown in respective wiring diagrams but is indicated on the next page.

**M: SYMBOLS AND ABBREVIATIONS**

A number of symbols and abbreviations are used in each wiring diagram to easily identify parts or circuits.

**N: ABBREVIATION LIST**

Abbr.	Full name
ABS	Antilock Brake System
ACC	Accessory
A/C	Air Conditioning
AD	Auto Down
AT	Automatic Transmission
AU	Auto Up
+B	Battery
DN	Down
DRL	Daytime Running Light
E	Ground
F/B	Fuse & Joint Box
FL1.5	Fusible link 1.5 mm <sup>2</sup>
IG	Ignition
Illumi.	Illumination
LH	Left Hand
Lo	Low
M	Motor
M/B	Main Fuse Box
MG	Magnet
Mi	Middle
OP	Optional Parts
PASS	Passing
RH	Right Hand
SBF	Slow Blow Fuse
S.M.J.	Super Multiple Junction
ST	Starter
SW	Switch
TCS	Traction Control System
UP	Up
WASH	Washer




## 5. How to Use Super Multiple Junction (S.M.J.)


### A: TERMINAL ARRANGEMENT

The "S.M.J." indicated in wiring diagrams is shown in a simplified form.


#### 1. LHD MODEL



#### 2. RHD MODEL



**B: INSTALLATION**




**Tightening torque:**

**5.9±1.5 N·m (0.6±0.15 kg·cm, 4.3±1.1 in·lb)**

**NOTE:**

- Align the cutout portion of one connector with that of other before tightening the connecting bolt.
- Do not tighten the bolt excessively since this may deform the connectors.


**C: EXPLANATION OF S.M.J. SHOWN IN THE WIRING DIAGRAM**



6. Wiring Diagram

A: POWER SUPPLY ROUTING


1. LHD MODEL





BU01-03A

# WIRING DIAGRAM

[D6A1] 6-3  
6. Wiring Diagram



- (F44)
- (B72)  
(Black)
- (F40)  
(Gray)
- (F41)  
(Gray)
- (F42)  
(Gray)
- (B51)  
(Gray)
- (B52)  
(Gray)
- (i5)  
(Gray)



## 6-3 [D6A1]

### 6. Wiring Diagram

## WIRING DIAGRAM

No.	Load
MB-1	Fuse holder (Rear power supply & seat heater)
MB-2	Power window circuit breaker
MB-3	Data link connector Engine control module Fuel pump relay Main relay
MB-4	A/C relay holder
MB-6	Headlight LH
MB-7	Daytime running light control module Diode (Lighting) Diode (Security) Lighting switch
MB-8	Combination meter Front fog light switch Headlight RH Front fog light relay
MB-9	Door lock timer Headlight alarm relay Radio Security control module Security indicator light Spot light Room light Step light Combination meter Luggage room light Trailer connector Trunk room light
MB-10	A/C relay holder
SBF-6	ABS relay box TCS motor relay
SBF-7	TCS valve relay
ALT-1	Combination meter Daytime running light control module Diode (TCS)
IG	Headlight alarm relay
ST	Cruise control module Engine control module Inhibitor switch (AT) Interrupt relay (with security) Starter interlock relay (MT)
FB-1	Front washer motor Rear washer motor
FB-2	Engine control module Main fan relay 1
FB-3	Sub fan relay 2 Sub fan motor
FB-4	Engine control module Fuel pump relay Ignition coil Transmission control module
FB-5	ABS relay box
FB-6	Side marker light LH Side marker light RH
FB-7	Door lock timer Keyless entry control module

No.	Load
FB-8	Wiper deicer relay
FB-9	Hazard switch
FB-10	AT shift lock control module Key warning switch Power antenna
FB-11	Radio
FB-12	Front accessory power supply
FB-13	Mirror heater Rear power supply relay Remote control rearview mirror switch Security control module Vanity mirror illumination light
FB-14	AT shift lock control module Combination switch Front wiper motor Rear wiper motor Rear wiper relay
FB-15	ABS/TCS control module Transmission control module
FB-16	Rear defogger Rear defogger condenser Rear defogger switch
FB-17	Rear defogger timer
FB-18	AT shift lock control module Back-up light switch (MT) Inhibitor switch (AT)
FB-19	Hazard switch
FB-20	A/C switch Combination meter Mode control panel Rear defogger timer TCS off switch
FB-22	Blower motor relay Check connector Daytime running light control module Daytime running light relay FRESH/RECIRC actuator Hi-beam relay Keyless entry control module Power window and sunroof relay Seat belt timer Security control module Vehicle speed sensor (MT) Wiper deicer relay Wiper deicer timer
FB-23	Airbag control module
FB-24	Airbag control module
FB-25	Lighting switch
FB-26	Keyless entry control module Parking switch
FB-27	Keyless entry control module Parking switch Security control module
FB-28	Illumination light
FB-29	Illumination light

# WIRING DIAGRAM

[D6A1] 6-3  
6. Wiring Diagram






No.	Load
FB-30	Pedal stroke switch Stop light switch Stop & brake switch
FB-31	Horn relay Siren (with security)
FB-32	Blower motor relay
FB-33	Parking switch Security control module
FB-34	License plate light Rear combination light LH Rear combination light RH Rear finisher light LH Rear finisher light RH
FB-35	ABS control module ABS/TCS control module TCS valve relay Cruise control main switch Cruise control module
FB-36	Front fog light relay
FB-37	Main fan relay 1

**6-3 [D6A2]**  
6. Wiring Diagram

**WIRING DIAGRAM**



**2. RHD MODEL**

- Battery current
- Current from ignition switch IG terminal
- - - Current from ignition switch ACC terminal
- Other currents



# WIRING DIAGRAM

[D6A2] **6-3**  
6. Wiring Diagram



BUR01-02B



## 6-3 [D6A2]

### 6. Wiring Diagram

## WIRING DIAGRAM

No.	Load
MB-2	Power window circuit breaker
MB-3	Engine control module Fuel pump relay Main relay OBD-II service connector
MB-4	A/C relay holder
MB-6	Headlight LH
MB-7	Diode (Lighting) Lighting switch
MB-8	Combination meter Headlight RH
MB-9	Combination meter Door lock timer Luggage room light Radio Room light
MB-10	A/C relay holder
ALT-1	Combination meter
IG	A/C relay holder
ST	Cruise control module Engine control module Inhibitor switch
FB-2	Engine control module Main fan relay 1
FB-3	Sub fan motor Sub fan relay-2
FB-4	Engine control module Fuel pump relay Ignition coil Transmission control module
FB-6	Side marker light LH Side marker light RH
FB-7	Door lock timer
FB-9	Hazard switch
FB-10	AT shift lock control module Key warning switch Power antenna
FB-11	Radio
FB-12	Cigarette lighter
FB-13	Remote control rearview mirror switch
FB-14	AT shift lock control module Combination switch Front washer motor Front wiper motor Rear washer motor Rear wiper motor Rear wiper relay
FB-15	Transmission control module
FB-16	Rear defogger Rear defogger condenser Rear defogger switch
FB-17	Rear defogger timer
FB-18	AT shift lock control module Inhibitor switch
FB-19	Hazard switch

No.	Load
FB-20	Combination meter Mode control panel Rear defogger timer
FB-22	Blower motor relay Check connector FRESH/RECIRC actuator Mode actuator Power window relay Seat belt timer
FB-23	Airbag control module
FB-24	Airbag control module
FB-25	Lighting switch
FB-26	Parking switch
FB-27	Parking switch
FB-28	Illumination light
FB-29	Illumination light
FB-30	Stop light switch Stop & brake switch
FB-31	Horn relay
FB-32	Blower motor relay
FB-33	Parking switch
FB-34	License plate light LH License plate light RH Rear combination light LH Rear combination light RH Rear finisher light LH Rear finisher light RH
FB-35	Cruise control main switch Cruise control module
FB-38	Main fan relay 1

# WIRING DIAGRAM

[D6A2] 6-3  
6. Wiring Diagram


---

MEMO:




# WIRING DIAGRAM

[D6B1] 6-3  
6. Wiring Diagram





**6-3 [D6B1]**  
6. Wiring Diagram

**WIRING DIAGRAM**



(2500 cc engine model)





BU04-08C

# WIRING DIAGRAM

[D6B1] 6-3  
6. Wiring Diagram

(2200 cc engine model)





BU04-08D



# WIRING DIAGRAM

[D6B2] 6-3  
6. Wiring Diagram





BP04-06B



# 6-3 [D6B2]



## 6. Wiring Diagram

# WIRING DIAGRAM




# WIRING DIAGRAM

## C: AIRBAG SYSTEM



D: AIR CONDITIONING SYSTEM



1. LHD MODEL



# WIRING DIAGRAM


[D6D2] **6-3**  
6. Wiring Diagram

## 2. RHD MODEL



A/C relay holder (Black)

E: ANTI-LOCK BRAKE SYSTEM




(B64) (Black)




(B65) (Black)




(F49)



(i14)





(i2)



# WIRING DIAGRAM



[D6E0] 6-3  
6. Wiring Diagram



BU82-06B


F: A/T CONTROL SYSTEM

1. LHD 2200 cc ENGINE MODEL



# WIRING DIAGRAM

[D6F1] 6-3  
6. Wiring Diagram




BU41-07B




# WIRING DIAGRAM

## 2. LHD 2500 cc ENGINE MODEL




\*1 : With cruise control



# WIRING DIAGRAM

[D6F2] 6-3  
6. Wiring Diagram





BU41-06B

**6-3 [D6F3]**  
6. Wiring Diagram

**WIRING DIAGRAM**

**3. RHD MODEL**





BP41-04A



G: A/T SHIFT LOCK SYSTEM



1. LHD MODEL

\*1 Without cruise control  
\*2 With cruise control




# WIRING DIAGRAM

## 2. RHD MODEL




H: AUDIO SYSTEM

1. LHD MODEL





\*1 : Sedan  
\*2 : Wagon



# WIRING DIAGRAM






[D6H2] 6-3  
6. Wiring Diagram

## 2. RHD MODEL






I: CHARGING SYSTEM




**MEMO:**

J: COMBINATION METER





# WIRING DIAGRAM

[D6J0] 6-3  
6. Wiring Diagram



BU65-05B

K: CRUISE CONTROL SYSTEM



# WIRING DIAGRAM

[D6K0] 6-3  
6. Wiring Diagram

---



MEMO:



# WIRING DIAGRAM

[D6L2] 6-3  
6. Wiring Diagram


## 2. RHD MODEL







M: ENGINE ELECTRICAL SYSTEM

1. LHD 2200 cc ENGINE CALIFORNIA MODEL



# WIRING DIAGRAM


[D6M1] 6-3  
6. Wiring Diagram



BU10-11B

**6-3 [D6M1]**  
**6. Wiring Diagram**

**WIRING DIAGRAM**




(E14) (Gray)

(E8) (Brown)




(B83)




(E28) (Black)




(B21) (Gray)



(E12) (Dark gray)




(B22)



BU10-11C

# WIRING DIAGRAM

[D6M1] 6-3  
6. Wiring Diagram



BU10-11D








# WIRING DIAGRAM


[D6M2] **6-3**  
6. Wiring Diagram




BU10-10D



3. LHD 2500 cc ENGINE MODEL





# WIRING DIAGRAM




**6-3 [D6M3]**  
**6. Wiring Diagram**

**WIRING DIAGRAM**



BU10-09C

# WIRING DIAGRAM



- (E15) (Dark gray)
- (E10) (Gray)
- (Light gray) (E5)
- (Dark gray) (E6)
- (Light gray) (E16)
- (Dark gray) (E17)



(B84) (Light blue)

(E4) (Blue)

(E7) (Gray)


(B20) (Light gray)




1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16																																				
17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44																								
45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96

# WIRING DIAGRAM

## 4. RHD CALIFORNIA MODEL




# WIRING DIAGRAM




**6-3 [D6M4]**  
6. Wiring Diagram

**WIRING DIAGRAM**



(Gray) (E14) (E8) (Brown)

(E12) (Dark gray)






(Black) (E13) (E28)

(B83)

(B21)

(B22)




BP10-07C






5. RHD EXCEPT CALIFORNIA MODEL





# WIRING DIAGRAM




**6-3 [D6M5]**  
**6. Wiring Diagram**

**WIRING DIAGRAM**



BP10-06C


# WIRING DIAGRAM




BP10-06D

N: FUEL GAUGE SYSTEM

1. TAIWAN MODEL





\*1...AWD : 3  
FWD : 6  
\*2...AWD : L  
FWD : G



# WIRING DIAGRAM

[D6N2] **6-3**  
6. Wiring Diagram



## 2. LHD EXCEPT TAIWAN MODEL



BU61-02

# WIRING DIAGRAM

## 3. RHD MODEL



BUR61-02

# WIRING DIAGRAM

[D6N3] 6-3  
6. Wiring Diagram


---

MEMO:



O: HORN AND FRONT ACCESSORY POWER SUPPLY SYSTEM

1. LHD MODEL



(i25)


(B49) (Black)



(B68) (Black)




(F44)



# WIRING DIAGRAM

[D602] **6-3**  
6. Wiring Diagram

## 2. RHD MODEL




(i25) (B49) (Black)



(B68) (Black)





(F44)



BUR74-01



P: LIGHTING SYSTEM (BACK-UP LIGHT)

1. LHD MODEL



# WIRING DIAGRAM



## 2. RHD MODEL



# WIRING DIAGRAM



## Q: LIGHTING SYSTEM (CLEARANCE LIGHT AND ILLUMINATION LIGHT)

### 1. LHD MODEL



# WIRING DIAGRAM



[D6Q1] 6-3  
6. Wiring Diagram



BU21-06B


# WIRING DIAGRAM

## 2. RHD MODEL



# WIRING DIAGRAM

[D6Q2] 6-3  
6. Wiring Diagram



(i27)	(i23) (Brown)	(i18) (i19) (Brown)	(i22)																																																																																
<table border="1"><tr><td>1</td><td>2</td></tr><tr><td>2</td><td>1</td></tr></table>	1	2	2	1	<table border="1"><tr><td>2</td><td>1</td></tr></table>	2	1	<table border="1"><tr><td>1</td><td>2</td></tr><tr><td>3</td><td>4</td></tr><tr><td>5</td><td>6</td></tr></table>	1	2	3	4	5	6	<table border="1"><tr><td>1</td><td>2</td><td>3</td><td>4</td></tr><tr><td>5</td><td>6</td><td>7</td><td>8</td></tr><tr><td>9</td><td>10</td><td>11</td><td>12</td></tr></table>	1	2	3	4	5	6	7	8	9	10	11	12																																																								
1	2																																																																																		
2	1																																																																																		
2	1																																																																																		
1	2																																																																																		
3	4																																																																																		
5	6																																																																																		
1	2	3	4																																																																																
5	6	7	8																																																																																
9	10	11	12																																																																																
(i26)	(i12) (Light gray)	(i17) (Black)	(i3) (Brown)																																																																																
<table border="1"><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td></tr><tr><td>7</td><td>8</td><td>9</td><td>10</td><td>11</td><td>12</td></tr><tr><td>13</td><td>14</td><td>15</td><td>16</td><td>17</td><td>18</td></tr></table>	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	<table border="1"><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td><td>8</td><td>9</td><td>10</td><td>11</td><td>12</td><td>13</td><td>14</td><td>15</td><td>16</td></tr></table>	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	<table border="1"><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td><td>8</td></tr><tr><td>9</td><td>10</td><td>11</td><td>12</td><td>13</td><td>14</td><td>15</td><td>16</td></tr></table>	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	<table border="1"><tr><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td><td>8</td><td>9</td><td>10</td></tr><tr><td>11</td><td>12</td><td>13</td><td>14</td><td>15</td><td>16</td><td>17</td><td>18</td><td>19</td><td>20</td></tr><tr><td>21</td><td>22</td><td></td><td></td><td></td><td></td><td></td><td></td><td></td><td></td></tr></table>	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22								
1	2	3	4	5	6																																																																														
7	8	9	10	11	12																																																																														
13	14	15	16	17	18																																																																														
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16																																																																				
1	2	3	4	5	6	7	8																																																																												
9	10	11	12	13	14	15	16																																																																												
1	2	3	4	5	6	7	8	9	10																																																																										
11	12	13	14	15	16	17	18	19	20																																																																										
21	22																																																																																		



BUR21-02B



# WIRING DIAGRAM

## R: LIGHTING SYSTEM (FRONT FOG LIGHT)


### 1. WITHOUT DRL MODEL



# WIRING DIAGRAM

[D6R2] **6-3**  
6. Wiring Diagram

## 2. WITH DRL MODEL



- (B85) (Black)    (F6) \*    (F7) (Black)    (B48) (Blue)    (B103) (Blue)    (i7) (Yellow)
- (B95) (Black)    (F21) \*    (F23) (Black)
- (B112) (Black)
- [2 1]    (1 2)    (1 2 3)    [1 2 / 3 4]    [1 X 2 / 3 4 5 6]
- (F44)    (B71)    (B69) (Black)    (i4) (Blue)    (F45)
- [1 2 3 4 / 5 6 7 8]    [1 2 3 4 / 5 6 7 8]    [1 2 3 4 5 / 6 7 8 9 10 11]    [1 2 3 4 5 / 6 7 8 9 10 / 11 12 13 14 15 16 / 17 18 19 20]

BC22-02



**MEMO:**

# WIRING DIAGRAM

[D6S1] **6-3**  
6. Wiring Diagram

## S: LIGHTING SYSTEM (HEADLIGHT)


### 1. WITHOUT DRL (LHD) MODEL



BU20-02



# WIRING DIAGRAM

## 2. WITH DRL (LHD) MODEL











# WIRING DIAGRAM

[D6S2] 6-3  
6. Wiring Diagram



BC20-03B

3. RHD MODEL



**MEMO:**






# WIRING DIAGRAM

[D6T2] 6-3  
6. Wiring Diagram

## 2. LHD WITHOUT KEYLESS ENTRY MODEL





(R32)	(R56)	(D20)	(D10)	(F46)	(Light gray)	(i10)	(i12)	(Light gray)	(R51)	(R54)	(D33)	(R20)	(D46)	(R52)	(R27)	(B30)	(B101)
	*1	*2 (Black)	(Black)	(Black)								(Blue)	(Black)				
1 2	1 1 2	1 1 2	1 2	1 2	1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16	1 2			1 2			1 2	1 2	1 1 2	2 1 1	1 2 3 4 5 6	7 8 9 10 11 12 13 14
(R30)	(R35)	(B35)	(B90)	(B45)	(B104) (Pink)	(B109)			(R45)		(D35)	(B97)					
(Black)		(Brown)															
1 2	3 2 1	1 2 3 4	1 2 3 4	1 2 3 4	1 2 3 4	1 2 3 4 5 6			1 2 3		1 2 3 4	1 2 3 4					
	(F45)				(Black)	(i1)	(i2)	(i3)	(Brown)		(Black)	(B98)	(B99)				
1 2 3 4 5 6 7 8 9 10					1 1 1 2 1 3 1 4 1 5 1 6 1 7 1 8 1 9 1 10 1 11 1 12 1 13 1 14 1 15 1 16 1 17 1 18 1 19 1 20 1 21 1 22						1 2 3 4 5 6 7 8 9 10 11	1 2 1 3 1 4 1 5 1 6 1 7 1 8 1 9 1 10 1 11 1 12 1 13 1 14 1 15 1 16 1 17 1 18 1 19 1 20 1 21 1 22 1 23 1 24					

**6-3 [D6T3]**  
6. Wiring Diagram

**WIRING DIAGRAM**



**3. LHD L. MODEL (FOR USA AND CANADA)**



# WIRING DIAGRAM

[D6T4] 6-3  
6. Wiring Diagram

## 4. RHD MODEL





BUR23-02

U: LIGHTING SYSTEM (STOP LIGHT)

1. LHD MODEL



- \*1 : Without cruise control
- \*2 : With cruise control
- \*3 : With TCS
- \*4 : Sedan
- \*5 : Wagon



# WIRING DIAGRAM

[D6U2] **6-3**  
6. Wiring Diagram

## 2. RHD MODEL





BUR25-01

# WIRING DIAGRAM

## V: LIGHTING SYSTEM (TURN SIGNAL LIGHT AND HAZARD LIGHT)



### 1. LHD MODEL



# WIRING DIAGRAM



[D6V2] **6-3**  
6. Wiring Diagram

## 2. RHD MODEL





W: OIL PRESSURE AND TEMPERATURE GAUGE SYSTEM





BU66-02

MEMO:

X: PARKING BRAKE AND BRAKE FLUID LEVEL WARNING SYSTEM


1. LHD MODEL



# WIRING DIAGRAM

[D6X2] **6-3**  
6. Wiring Diagram

## 2. RHD MODEL




(B16) (Gray)



(i14)



(i10) (Light gray)



(F45)





(i1) (Black)



BUR60-02


Y: POWER WINDOW SYSTEM

1. LHD MODEL




# WIRING DIAGRAM

[D6Y1] 6-3  
6. Wiring Diagram





BU70-04B

2. RHD MODEL







(Green) (B41)  
(Green) (D3) (D13) (Green)  
(Green) (D30) (D24) (Green)

(B42)



# WIRING DIAGRAM

[D6Y2] 6-3  
6. Wiring Diagram




BUR70-02B



Z: RADIATOR FAN SYSTEM


1. LHD MODEL



(B134)



(F16) (Black)

(F17) (Black)




(F45)

(B84) (Light blue)




# WIRING DIAGRAM

## 2. RHD MODEL




F16 (Black)  
F17 (Black)



F44




F45




F27 F28 F29 F30 F31

B134





A/C relay holder (Black)



AA: REAR WINDOW DEFOGGER SYSTEM


1. LHD MODEL



# WIRING DIAGRAM

[D6AA2] **6-3**  
6. Wiring Diagram

## 2. RHD MODEL



D33  
R25 (Black)

i37

i18

i4 (Blue)




BP52-02

# WIRING DIAGRAM

## AB: REMOTE CONTROLLED REARVIEW MIRROR SYSTEM

### 1. LHD MODEL



\* : Outback step roof model

\* D6

\* D16




D5 D15

i6

i12

\* i13 (Brown)

B30 B101




BU79-02

# WIRING DIAGRAM

[D6AB2] 6-3  
6. Wiring Diagram

## 2. RHD MODEL






(D5) (D15)

(i6)

(i2)

(B30) (B101)






# WIRING DIAGRAM

[D6AC2] **6-3**  
6. Wiring Diagram

## 2. RHD MODEL




(R8) (B74) (Black)




(B44)




(i14)



(i10) (Light gray)





(i4) (Blue)







AD: SEAT HEATER SYSTEM



MEMO:



AE: SECURITY SYSTEM



BU102-03A

# WIRING DIAGRAM

[D6AE0] 6-3  
6. Wiring Diagram






# WIRING DIAGRAM

[D6AG0] **6-3**  
6. Wiring Diagram


## AG: SUNROOF SYSTEM



BU75-03

AH: WIPER AND WASHER SYSTEM (FRONT)

1. LHD MODEL




F32 (Green)



B8



B70




F45



# WIRING DIAGRAM

## 2. RHD MODEL




(B110) (Green)



(B8)



(B70)







# WIRING DIAGRAM


## AI: WIPER AND WASHER SYSTEM (REAR)

### 1. LHD MODEL



# WIRING DIAGRAM

## 2. RHD MODEL



(B29)



(D33)



(D43)




(D34)




(R36) (Black)



(B70)



AJ: WIPER DEICER SYSTEM





(B178)

(B177) (Gray)

(R88)



(R87) (Blue)

(R86)




MEMO:

AK: KEYLESS ENTRY AND SECURITY SYSTEM




# WIRING DIAGRAM

**[D6AK0] 6-3**  
6. Wiring Diagram




(R52) (B90) (Black) (i1) (i2) (i3) (Brown) (i8) (Brown) (i12) (Light gray) (B30) (B101) (B113)



BU94-04B

# WIRING DIAGRAM

## AL: FRONT FOG LIGHT SYSTEM (OPTION)




OP3 OP4

OP1



(Yellow) OP2 B43 (Black)

B71




F45 i4 (Blue)

i3 (Brown)



# WIRING DIAGRAM

## AM: MULTIPLE POWER SOCKET SYSTEM (OPTION)



i25



OP1 (Blue)



BU92-01



AN: TRAILER WIRE HARNESS (OPTION)



## 7. Electrical Unit Location


### A: LIST

Electrical unit	Index No.
ABS control module	<Ref. to 4-4 [T300].>
ABS G sensor (MT)	<Ref. to 4-4 [T300].>
A/C compressor relay	<Ref. to 6-3 [D7B1].>
A/C fuse	<Ref. to 6-3 [D7B1].>
A/C main fan relay 1	<Ref. to 6-3 [D7B1].>
A/C main fan relay 2	<Ref. to 6-3 [D7B1].>
A/C pressure switch	<Ref. to 6-3 [D7B1].>
A/C sub fan relay 2	<Ref. to 6-3 [D7B1].>
ATF temperature sensor	<Ref. to 2-7 [T2D2].>
Blower motor resistor	<Ref. to 6-3 [D7B2].>
Blower relay	<Ref. to 6-3 [D7B2].>
Camshaft position sensor	<Ref. to 2-7 [T2A2].>
Check connector	<Ref. to 6-3 [D7B2].>
Clutch switch (MT)	<Ref. to 6-2a [T300].>
Crankshaft position sensor	<Ref. to 2-7 [T2A2].>
Cruise control module	<Ref. to 6-2a [T300].>
Cruise control pump	<Ref. to 6-2a [T300].>
Data link connector (for OBD-II G.S.T.)	<Ref. to 2-7 [T2A3].>
Data link connector (for S.S.M.)	<Ref. to 2-7 [T2A3].>
Diagnosis connector	<Ref. to 4-4 [T300].>
Diagnosis terminal (Ground)	<Ref. to 4-4 [T300].>
Door lock timer	<Ref. to 6-3 [D7B2].>
Engine control module	<Ref. to 2-7 [T2A1].>
Engine coolant temperature sensor	<Ref. to 2-7 [T2A2].>
Engine hood switch (Security)	<Ref. to 6-2b [T6A0].>
Evaporator thermostwitch	<Ref. to 6-3 [D7B2].>
F/B	<Ref. to 6-3 [D7B2].>
FRESH/RECIRC actuator	<Ref. to 6-3 [D7B2].>
Fuel pump relay	<Ref. to 2-7 [T2A3].>
Fuel gauge module	<Ref. to 6-3 [D7B3].>
Fuel gauge sub module (AWD)	<Ref. to 6-3 [D7B3].>
FWD switch (AT)	<Ref. to 6-3 [D7B1].>
Headlight alarm relay (Security)	<Ref. to 6-2b [T6A0].>
Headlight relay LH	<Ref. to 6-3 [D7B1].>

Electrical unit	Index No.
Headlight relay RH	<Ref. to 6-3 [D7B1].>
Horn relay	<Ref. to 6-3 [D7B2].>
Hydraulic unit (ABS)	<Ref. to 4-4 [T300].>
Ignition coil	<Ref. to 2-7 [T2A3].>
Ignitor	<Ref. to 2-7 [T2A3].>
Idle air control solenoid valve	<Ref. to 2-7 [T2A3].>
Illumination control module	<Ref. to 6-3 [D7B2].>
Inhibitor switch	<Ref. to 6-2a [T300].>
Knock sensor	<Ref. to 2-7 [T2A2].>
Main fan relay	<Ref. to 6-3 [D7B2].>
Main relay	<Ref. to 2-7 [T2A3].>
Mass air flow sensor	<Ref. to 2-7 [T2A2].>
Mode actuator	<Ref. to 6-3 [D7B2].>
M/B	<Ref. to 6-3 [D7B1].>
Oil pressure switch	<Ref. to 6-3 [D7B1].>
Oxygen sensor	<Ref. to 2-7 [T2A2].>
Pedal stroke sensor (TCS)	<Ref. to 4-4 [T300].>
Power window and sunroof relay	<Ref. to 6-3 [D7B2].>
Power window circuit breaker	<Ref. to 6-3 [D7B2].>
Purge control solenoid valve	<Ref. to 2-7 [T2A3].>
Rear defogger relay	<Ref. to 6-3 [D7B2].>
Seat belt timer	<Ref. to 6-3 [D7B2].>
Security control module	<Ref. to 6-2b [T6A0].>
Shift lock control module	<Ref. to 6-3 [D7B2].>
Starter interrupt relay (Security)	<Ref. to 6-2b [T6A0].>
Stop & brake switch (With cruise control)	<Ref. to 6-2a [T300].>
Sunroof control module	<Ref. to 6-3 [D7B3].>
Tail and illumination relay	<Ref. to 6-3 [D7B2].>
TCS control module	<Ref. to 4-4 [T300].>
TCS motor relay	<Ref. to 4-4 [T300].>
TCS valve relay	<Ref. to 4-4 [T300].>
Throttle position sensor	<Ref. to 2-7 [T2A2].>
Test mode connector	<Ref. to 2-7 [T2A3].>
Transmission control module	<Ref. to 2-7 [T2D1].>
Turn & hazard module	<Ref. to 6-3 [D7B2].>
Vehicle speed sensor 1	<Ref. to 2-7 [T2D2].>
Vehicle speed sensor 2	<Ref. to 2-7 [T2D2].>

**B: LOCATION**


**1. ENGINE ROOM**



B2M0018F

- |   |  |   |
|---|--|---|
| (1) FWD switch (AT) <Ref. to 6-3 [D7B4].>     | (5) Headlight relay LH <Ref. to 6-3 [D7B4].>   | (8) A/C main fan relay 2 <Ref. to 6-3 [D7B4].>  |
| (2) A/C pressure switch <Ref. to 6-3 [D7B4].> | (6) Headlight relay RH <Ref. to 6-3 [D7B4].>   | (9) A/C sub fan relay 2 <Ref. to 6-3 [D7B4].>   |
| (3) Oil pressure switch <Ref. to 6-3 [D7B4].> | (7) A/C compressor relay <Ref. to 6-3 [D7B4].> | (10) A/C main fan relay 1 <Ref. to 6-3 [D7B4].> |
| (4) M/B <Ref. to 6-3 [D7B4].>                 |  | (11) A/C fuse <Ref. to 6-3 [D7B4].>             |



## 2. INSTRUMENT PANEL



B6M0218D

- |  |  |   |
|--|--|---|
| <p>(12) Mode actuator &lt;Ref. to 6-3 [D7B4].&gt;</p> <p>(13) Blower relay &lt;Ref. to 6-3 [D7B4].&gt;</p> <p>(14) Horn relay &lt;Ref. to 6-3 [D7B4].&gt;</p> <p>(15) F/B &lt;Ref. to 6-3 [D7B4].&gt;</p> <p>(16) Turn &amp; hazard module &lt;Ref. to 6-3 [D7B4].&gt;</p> <p>(17) Rear defogger relay &lt;Ref. to 6-3 [D7B4].&gt;</p> <p>(18) Tail &amp; illumination relay &lt;Ref. to 6-3 [D7B4].&gt;</p> | <p>(19) Main fan relay &lt;Ref. to 6-3 [D7B4].&gt;</p> <p>(20) Seat belt timer &lt;Ref. to 6-3 [D7B4].&gt;</p> <p>(21) Illumination control module &lt;Ref. to 6-3 [D7B4].&gt;</p> <p>(22) Shift lock control module &lt;Ref. to 6-3 [D7B4].&gt;</p> <p>(23) Power window circuit breaker &lt;Ref. to 6-3 [D7B4].&gt;</p> <p>(24) Power window &amp; sunroof relay &lt;Ref. to 6-3 [D7B4].&gt;</p> | <p>(25) Check connector &lt;Ref. to 6-3 [D7B4].&gt;</p> <p>(26) Blower motor resistor &lt;Ref. to 6-3 [D7B4].&gt;</p> <p>(27) Door lock timer &lt;Ref. to 6-3 [D7B4].&gt;</p> <p>(28) FRESH/RECIRC actuator &lt;Ref. to 6-3 [D7B4].&gt;</p> <p>(29) Evaporator thermoswitch &lt;Ref. to 6-3 [D7B4].&gt;</p> |
|--|--|---|

3. COMPARTMENT




(30) Sunroof control module <Ref. to 6-3 [D7B4].>

(31) Fuel gauge module <Ref. to 6-3 [D7B4].>






(32) Fuel gauge sub module (AWD) <Ref. to 6-3 [D7B4].>

## 4. DETAIL



**6-3 [D7B4]**  
7. Electrical Unit Location

**WIRING DIAGRAM**

 <p>(25)</p> <p>B6M0230C</p>	 <p>(29)</p> <p>(26)</p> <p>(27)</p> <p>B6M0231C</p>
 <p>(28)</p> <p>B6M0495B</p>	 <p>(29)</p> <p>(26)</p> <p>(27)</p> <p>B6M0231C</p>
 <p>(31)</p> <p>(32)</p> <p>B6M0235C</p>	<p><b>SUBARU.</b></p>

# WIRING DIAGRAM

[D7B4] 6-3  
7. Electrical Unit Location

---


MEMO:



8. Electrical Wiring Harness and Ground Point

A: OVERALL LOCATION


1. LHD MODEL



B6M0267B

- |                                     |  |                              |
|-------------------------------------|--|------------------------------|
| (1) Front wiring harness            | (8) Rear wiring harness                | (14) Sunroof cord            |
| (2) Engine wiring harness           | (9) Trunk lid cord (Sedan)             | (15) Floor wiring harness    |
| (3) Room light cord                 | (10) Rear defogger ground cord (Sedan) | (16) Transmission cord       |
| (4) Bulkhead wiring harness         | (11) Fuel tank cord                    | (17) Rear gate cord (Wagon)  |
| (5) Instrument panel wiring harness | (12) Rear door cord LH                 | (18) Rear oxygen sensor cord |
| (6) Front door cord RH              | (13) Front door cord LH                |                              |
| (7) Rear door cord RH               |  |                              |

## 2. RHD MODEL



B6M0510B

- |                                     |                         |                              |
|-------------------------------------|-------------------------|------------------------------|
| (1) Front wiring harness            | (6) Front door cord RH  | (11) Front door cord LH      |
| (2) Engine wiring harness           | (7) Rear door cord RH   | (12) Transmission cord       |
| (3) Room light cord                 | (8) Rear wiring harness | (13) Rear gate cord          |
| (4) Bulkhead wiring harness         | (9) Fuel tank cord      | (14) Rear oxygen sensor cord |
| (5) Instrument panel wiring harness | (10) Rear door cord LH  |                              |

**B: FRONT WIRING HARNESS****1. LHD MODEL**


Connector				Connecting to	
No.	Pole	Color	Area	No.	Name
F1	20	Blue	B-2	P1	Floor wiring harness (With TCS model)
	8	*	B-2	P1	Floor wiring harness (With ABS model)
F2	20	Blue	B-2	B100	Bulkhead wiring harness (With ABS model)
F3	3	Brown	B-1		Front turn signal and side marker light RH
F5	1	Black	B-1		Horn
F6	2	*	C-1		Front fog light RH
	2	Brown	C-1		Front fog light RH (Outback with step roof)
F7	3	Black	B-1		Headlight RH
F10	4	*	B-2		TCS motor relay
F11	6	*	B-2		TCS valve relay
F12	2	Black	B-2		TCS pressure switch
F13	2	Black	B-2		TCS motor
F14	2	Gray	B-2		Hydraulic unit (TCS)
F15	12	Gray	B-2		
F16	3	Black	C-1		Sub fan motor
F17	3	Black	C-2		Radiator main fan motor
F18	2	Gray	C-3		Front hood switch (Security)
F19	3	Brown	C-3		Front turn signal and side marker light LH
F21	2	*	C-2		Front fog light LH
	2	Brown	C-2		Front fog light LH (Outback with step roof)
F23	3	Black	C-2		Headlight LH
F24	3	Gray	B-2		A/C compressor
F25	1 × 2	*	B-2		Generator
F26	2	Gray	B-2		
F27	4	Black	B-3		A/C fuse (Relay holder)
F28	4	Black	B-3		A/C main fan relay-1 (Relay holder)
F29	4	Black	B-3		A/C sub fan relay-2 (Relay holder)
F30	4	Black	B-3		A/C main fan relay-2 (Relay holder)
F31	4	Black	B-3		A/C relay (Relay holder)
F32	2	Green	B-2		Front washer motor
F33	2	*	B-3		Rear washer motor
F34	4	Black	B-3		SBF holder
F35	8	Black	B-3		M/B
F36	3	*	B-3		
F37	2	Black	B-3		
F38	2	Black	B-3		
F39	1	Brown	B-3		
F40	10	Gray	B-4		F/B
F41	3	Gray	B-4		
F42	5	Gray	B-4		
F43	3	Orange	B-4		A/C diode
F44	8	*	B-3	B61	Bulkhead wiring harness
F45	20	*	B-3	B62	
F46	2	Black	B-4	B108	Bulkhead wiring harness (Outback)
F47	1	Black	C-3		Horn (TAIWAN model)
F48	6	*	B-3		Shield joint connector (ABS)
F49	31	Black	B-1		ABS control module and hydraulic control module
F73	1	*	B-1		ABS pump motor ground

\*: Non-colored

# WIRING DIAGRAM

[D8B1] 6-3

## 8. Electrical Wiring Harness and Ground Point



## 6-3 [D8B2]

## WIRING DIAGRAM

### 8. Electrical Wiring Harness and Ground Point

#### 2. RHD MODEL


Connector				Connecting to	
No.	Pole	Color	Area	No.	Name
F3	3	Brown	B-1		Front turn signal and side marker light RH
F5	1	Black	B-1		Horn
F7	3	Black	B-1		Headlight RH
F16	3	Black	C-1		Sub fan motor
F17	3	Black	C-2		Radiator main fan motor
F19	3	Brown	C-3		Front turn signal and side marker light LH
F20	1	Black	C-2		Horn
F23	3	Black	C-2		Headlight LH
F24	1	Black	B-2		A/C compressor
F25	1 × 2	*	B-2		Generator
F26	2	Gray	B-2		
F27	4	Black	B-3		A/C fuse (Relay holder)
F28	4	Black	B-3		A/C main fan relay-1 (Relay holder)
F29	4	Black	B-3		A/C sub fan relay-2 (Relay holder)
F30	4	Black	B-3		A/C main fan relay-2 (Relay holder)
F31	4	Black	B-3		A/C relay (Relay holder)
F35	8	Black	B-3		M/B
F38	2	Black	B-3		
F40	10	Gray	B-2		F/B
F42	5	Gray	B-2		
F43	3	Orange	B-2		A/C diode
F44	8	*	B-2	B61	Bulkhead wiring harness
F45	20	*	B-2	B62	
F47	2	Gray	C-2		A/C pressure switch
F48	2	Blue	B-2		Thermal protector

\*: Non-colored

# WIRING DIAGRAM

[D8B2] 6-3

## 8. Electrical Wiring Harness and Ground Point



**C: BULKHEAD WIRING HARNESS (IN ENGINE ROOM)****1. LHD MODEL**


Connector				Connecting to	
No.	Pole	Color	Area	No.	Name
B1	2	*	B-2		Pressure source switching solenoid (2500 cc engine model)
B2	3	Black	B-2		Boost sensor (2500 cc engine model)
B3	5	Gray	B-2		Mass air flow sensor (2500 cc engine model)
B4	4	Gray	B-2		AT dropping resistor
B5	2	Gray	B-2		Resistor (Daytime running light)
B6	2	Gray	B-2		ABS front sensor RH
	2	Brown	B-2		ABS front sensor RH (Outback with step roof)
B7	4	*	B-2		Cruise control pump
B8	6	*	A-2		Front wiper motor
B9	2	Black	A-2		FWD switch (AT)
B10	2	Brown	B-2		A/C pressure switch
B11	20	*	B-3	T4	Transmission (AT)
B12	12	Gray	B-2	T3	
B13	6	Gray	B-3		Ignitor (2500 cc engine model)
B14	1	Black	B-3		Starter (Magnet)
B15	2	Gray	B-3		ABS front sensor LH
	2	Brown	B-3		ABS front sensor LH (Outback with step roof)
B16	2	Gray	B-3		Brake fluid level switch
B17	3	*	B-2		Vehicle speed sensor (MT)
B18	3	Dark gray	B-2		Front oxygen sensor (2500 cc engine model)
B19	4	*	B-2	T5	Rear oxygen sensor cord (2500 cc engine except California model)
	4	*	B-2		Rear oxygen sensor (2500 cc engine California model)
B20	6	Light gray	B-2	E1	Engine wiring harness (2500 cc engine model)
	10	*	B-2	E1	Engine wiring harness (2200 cc engine model)
B21	12	Light gray	B-2	E2	Engine wiring harness (2500 cc engine model)
	20	*	B-2	E2	Engine wiring harness (2200 cc engine model)
B22	16	Light gray	B-2	E3	
B24	2	Gray	B-2	T1	Back-up light switch (MT)
B25	2	Brown	B-2	T2	Neutral position switch (MT)
B177	3	Gray	A-3		Wiper deicer

\*: Non-colored

# WIRING DIAGRAM

[D8C1] 6-3

## 8. Electrical Wiring Harness and Ground Point





**6-3 [D8C2]****WIRING DIAGRAM**

## 8. Electrical Wiring Harness and Ground Point

**2. RHD MODEL**


Connector				Connecting to	
No.	Pole	Color	Area	No.	Name
B4	4	Gray	B-2		AT dropping resistor
B7	4	Gray	B-3		Cruise control pump
B8	6	*	B-3		Front wiper motor
B9	2	Black	A-2		FWD switch
B11	20	*	B-3	T4	Transmission
B12	12	Gray	B-2	T3	
B14	1	Black	B-3		Starter (Magnet)
B16	2	Gray	B-2		Brake fluid level switch
B17	2	Black	B-3		Vehicle speed sensor (MT)
B20	10	*	B-2	E1	Engine wiring harness
B21	20	*	B-2	E2	
B22	16	*	B-2	E3	
B26	2	Black	B-3		M/B
B27	3	*	B-3		
B28	1	Brown	B-3		
B29	2	*	B-2		Rear washer motor
B110	2	Green	B-3		Front washer motor

\*: Non-colored

# WIRING DIAGRAM

[D8C2] 6-3

## 8. Electrical Wiring Harness and Ground Point



# 6-3 [D8D1]

# WIRING DIAGRAM

## 8. Electrical Wiring Harness and Ground Point

### D: BULKHEAD WIRING HARNESS (IN COMPARTMENT)

#### 1. LHD MODEL

Connector				Connecting to	
No.	Pole	Color	Area	No.	Name
B30	24	*	C-1	D1	Front door cord LH
B31	7	Yellow	C-1	AB1	SRS (Airbag) harness
B32	3	Black	C-1		Turn & hazard module
B33	4	Brown	B-1		Diode (Brake fluid level)
B35	2	Black	B-1		Diode (Without step light)
	4	Brown	B-1		Diode (With step light)
B36	22	Black	C-1	i1	Instrument panel wiring harness
B37	22	*	C-1	i2	
B38	22	Brown	C-1	i3	
B39	20	Blue	C-1	i4	
B40	16	Gray	C-2		Data link connector
B41	2	*	C-2		Power window circuit breaker
B42	4	*	C-2		Power window and sunroof relay
B43	6	Black	C-2		Illumination control module
B44	8	*	C-2		Seat belt timer
B45	4	*	B-1	R53	Sunroof cord
B46	4	Green	B-1		Fuel pump relay
B47	6	Brown	B-1		Main relay
B48	4	Blue	B-1		Front fog light relay
B49	3	Black	B-1		Horn relay
B50	4	*	B-1		Blower relay
B51	11	Gray	B-1		F/B
B52	12	Gray	B-1		
B53	6	Gray	B-2		Shield joint connector (AT)
B54	24	*	B-2		Transmission control module
B55	24	Gray	B-2		
B57	12	Black	B-2		Shift-lock control module
B59	3	*	B-1		Interrupt relay (Security)
B60	4	*	B-2		Shield joint connector (With TCS model)
B61	8	*	B-2	F44	Front wiring harness
B62	20	*	B-1	F45	
B63	40	Gray	B-1	P10	Floor harness (With TCS model)
B64	2	Black	B-2		Stop light switch
B65	4	Black	B-2		Stop & brake switch (With cruise control)
B66	3	Black	B-2		Pedal stroke sensor (TCS)
B67	4	Black	B-2		Pedal stroke switch (TCS)
B68	5	Black	B-3		Slip ring
B69	11	Black	B-3		Combination switch
B70	9	*	B-3		
B71	8	*	B-3		
B72	6	Black	B-3		Ignition switch
B73	2	Black	B-3		Key lock solenoid (AT)
B74	2	Black	B-3		Key warning switch
B75	2	Green	C-2	B76	Test mode connector
B76	2	Green	C-3	B75	
B77	10	Brown	B-2		Mode actuator
B79	14	Gray	C-2		Check connector
B80	4	Blue	B-2	i20	Instrument panel wiring harness

Connector				Connecting to	
No.	Pole	Color	Area	No.	Name
B81	1 × 2	*	C-2		Diagnosis terminal (Ground)
B82	6	Black	C-2		Diagnosis connector
B83	4	*	C-3		Shield joint connector (2500 cc engine model)
	6	*	D-4		Shield joint connector (2200 cc engine model)
B84	96	Light blue	B-3		Engine control module (2500 cc engine model)
B86	4	*	B-3		Blower motor resistor
B87	2	*	B-3		Blower motor
B88	3	Black	B-3		Evaporator thermostitch
B89	2	Black	B-3		Diode (Security)
B90	4	*	B-4	R50	Room light cord
B91	4	*	B-4		FRESH/RECIRC actuator
B92	8	*	B-4		Door lock timer
B93	18	*	C-2		Security control module
B94	20	Black	B-4		Cruise control module
B95	2	Black	B-4		Diode (Daytime running light)
B96	10	*	B-4		Daytime running light control module
B97	8	*	B-4	R1	Rear wiring harness
B98	24	Black	B-4	R2	Rear wiring harness
B99	24	*	B-4	R3	Rear wiring harness
B100	20	Blue	B-4	F2	Front wiring harness (With ABS model)
B101	24	*	B-4	D11	Front door cord RH
B102	5	Black	B-4		Daytime running light relay
B103	4	Blue	B-4		High-beam relay (Daytime running light)
B104	4	Pink	B-4		Rear power supply relay
B105	5	Green	B-1		Starter interlock relay (MT)
B106	2	*	B-1		Clutch switch (MT)
B107	2	Blue	B-1		Clutch switch (Cruise control)
B108	2	Black	B-2	F46	Front wiring harness (Outback)
B109	4	Black	C-1		Fuse holder (Outback)
B112	2	Black	B-1		Diode (Front fog light)
B113	2	*	C-1	D50	Front door cord LH
B134	35	*	D-4		Engine control module (2200 cc engine model)
B135	28	*	D-4		
B136	30	*	C-4		
B176	16	*	B-2		Keyless entry control module
B178	3	*	B-4	R85	Rear wiring harness (Wiper deicer)
B183	1	*	C-1	B184	Program connector (Security)
B184	1	*	C-1	B183	
B205	2	*	B-2		Keyless entry short connector


\*: Non-colored

Connector				Connecting to	
No.	Pole	Color	Area	No.	Name
S1	3	White	D-3		Cruise control sub switch

# WIRING DIAGRAM

[D8D1] 6-3

## 8. Electrical Wiring Harness and Ground Point



## 6-3 [D8D2]

## WIRING DIAGRAM

### 8. Electrical Wiring Harness and Ground Point

#### 2. RHD MODEL

Connector				Connecting to	
No.	Pole	Color	Area	No.	Name
B30	24	*	C-4	D1	Front door cord RH
B31	7	Yellow	C-4	AB1	SRS (Airbag) harness
B32	3	Black	C-4		Turn & hazard module
B36	22	Black	C-3	i1	Instrument panel wiring harness
B37	22	*	C-3	i2	
B38	22	Brown	C-3	i3	
B39	20	Blue	C-3	i4	
B40	16	Gray	C-3		Data link connector
B41	2	*	C-3		Power window circuit breaker
B42	4	*	C-3		Power window relay
B43	6	Black	C-3		Illumination control module
B44	8	*	C-3		Seat belt timer
B46	4	Green	B-4		Fuel pump relay
B47	6	Brown	B-4		Main relay
B49	3	Black	B-4		Horn relay
B50	4	*	B-4		Blower relay
B51	11	Gray	C-4		F/B
B52	12	Gray	C-4		
B53	6	Gray	B-3		Shield joint connector (AT)
B54	24	*	B-3		Transmission control module
B55	24	Gray	B-3		
B57	12	Black	B-3		Shift-lock control module
B61	8	*	B-4	F44	Front wiring harness
B62	20	*	B-4	F45	
B64	2	Black	B-3		Stop light switch
B65	4	Black	B-3		Stop & brake switch (With cruise control)
B68	5	Black	B-3		Cruise control sub switch
B69	11	Black	C-3		Combination switch
B70	9	*	C-3		
B71	8	*	B-3		
B72	6	Black	C-3		Ignition switch
B73	2	Black	B-3		Key lock solenoid
B74	2	Black	B-3		Key warning switch
B75	2	Green	B-2	B76	Test mode connector
B76	2	Green	B-2	B75	
B77	7	*	B-2		Mode actuator
B78	9	Yellow	B-2		Data link connector
B79	14	Gray	C-2		Check connector
B80	4	Blue	B-2	i20	Instrument panel wiring harness

Connector				Connecting to	
No.	Pole	Color	Area	No.	Name
B81	1 × 2	*	B-2		Diagnosis terminal (Ground)
B82	6	Black	B-2		Diagnosis connector
B83	6	*	C-1		Shield joint connector (E/G)
B85	4	Brown	B-3		Diode (Lighting)
B86	4	Black	B-1		Blower motor resistor
B87	2	Black	B-1		Blower motor
B88	3	Black	B-1		Evaporator thermostat
B90	2	Green	B-4	R50	Room light cord
B91	5	*	B-1		FRESH/RECIRC actuator
B92	8	*	B-1		Door lock timer
B94	20	Black	B-1		Cruise control module
B97	56	*	B-4	R1	Rear wiring harness (S.M.J.)
B101	24	*	B-1	D11	Front door cord LH
B111	3	Gray	C-4		F/B
B113	2	*	C-4	D50	Front door cord RH
B114	2	Black	C-3		Diode (Door warning)
B134	35	*	C-2		Engine control module
B135	28	*	C-2		
B136	30	*	C-2		

\*: Non-colored



**E: ENGINE WIRING HARNESS AND TRANSMISSION CORD****1. 2200 cc ENGINE MODEL**

Connector				Connecting to	
No.	Pole	Color	Area	No.	Name
E1	10	*	A-3/B-2	B20	Bulkhead wiring harness
E2	20	*	A-3/B-2	B21	
E3	16	*	A-3/B-2	B22	
E4	2	Blue	A-3/B-1		Purge control solenoid valve
E5	2	Gray	A-3/B-1		Injector #1
E6	2	Gray	A-3/B-1		Injector #3
E7	3	Gray	A-4		Idle air control solenoid valve (California model)
	6	*	B-2		Idle air control solenoid valve (Except California model)
E8	2	Brown	A-3/B-1		Engine coolant temperature sensor
E9	1	*	A-3/B-1		Thermometer
E10	2	Gray	B-1/B-3		Crankshaft position sensor
E11	1	*	B-1/B-3		Oil pressure switch
E12	4	Gray	A-3/B-1		Ignition coil
E13	3	Black	A-3		Throttle position sensor (California model)
	4	Brown	B-2		Throttle position sensor (Except California model)
E14	2	Gray	A-4/B-2		Knock sensor
E15	2	Dark gray	B-4/C-2		Camshaft position sensor
E16	2	Gray	B-2/B-4		Injector #2
E17	2	Gray	B-2/B-4		Injector #4
E20	2	Black	A-4		Intake air temperature sensor
E21	3	*	A-1		Pressure sensor
E24	3	*	A-1		Front oxygen sensor (Except California model)
	4	*	A-3		Front oxygen (A/F) sensor (California model)
E25	4	*	A-1/A-3		Rear oxygen sensor
E26	5	Gray	B-1		Mass air flow sensor
E27	2	*	A-1		Pressure sources switching solenoid
E28	3	*	A-4		Intake manifold pressure sensor

\*: Non-colored


Connector				Connecting to	
No.	Pole	Color	Area	No.	Name
T1	2	Gray	D-1	B24	Bulkhead wiring harness (MT)
T2	2	Brown	D-1	B25	
T3	12	Gray	D-3	B12	Bulkhead wiring harness (AT)
T4	16	Gray	D-3	B11	
T5	4	Gray	C-1/D-3	B19	Bulkhead wiring harness
T6	4	Gray	D-2/D-4		Rear oxygen sensor
T7	12	*	D-4		Inhibitor switch (AT)

\*: Non-colored

# WIRING DIAGRAM

[D8E1] 6-3

## 8. Electrical Wiring Harness and Ground Point





**6-3 [D8E2]****WIRING DIAGRAM****8. Electrical Wiring Harness and Ground Point****2. 2500 cc ENGINE MODEL**

Connector				Connecting to	
No.	Pole	Color	Area	No.	Name
E1	6	*	A-3	B20	Bulkhead wiring harness
E2	12	Gray	A-3	B21	
E3	16	Gray	A-3	B22	
E4	2	Blue	A-2		Purge control solenoid valve
E5	2	Light gray	A-2		Injector #1
E6	2	Dark gray	A-3		Injector #3
E7	3	Gray	A-3		Idle air control solenoid valve
E8	2	Brown	B-3		Engine coolant temperature sensor
E9	1	*	B-3		Thermometer
E10	2	Gray	B-3		Crankshaft position sensor
E11	1	*	B-3		Oil pressure switch
E12	3	Gray	A-3		Ignition coil
E13	3	Brown	A-3		Throttle position sensor
E14	2	Gray	B-3		Knock sensor
E15	2	Dark gray	B-4		Camshaft position sensor
E16	2	Light gray	B-4		Injector #2
E17	2	Dark gray	B-4		Injector #4
E18	2	Brown	B-3		EGR solenoid (AT)

\*: Non-colored


Connector				Connecting to	
No.	Pole	Color	Area	No.	Name
T1	2	Gray	C-1	B24	Bulkhead wiring harness (MT)
T2	2	Brown	C-1	B25	
T3	12	Gray	D-3	B12	Bulkhead wiring harness (AT)
T4	16	Gray	D-3	B11	
T5	4	Gray	C-1/C-3	B19	Bulkhead wiring harness
T6	4	Gray	D-2/D-4		Rear oxygen sensor
T7	12	*	C-4		Inhibitor switch (AT)

\*: Non-colored

# WIRING DIAGRAM

[D8E2] 6-3

## 8. Electrical Wiring Harness and Ground Point



## F: INSTRUMENT PANEL WIRING HARNESS

## 1. LHD MODEL


Connector				Connecting to	
No.	Pole	Color	Area	No.	Name
i1	22	Black	C-2	B36	Bulkhead wiring harness
i2	22	*	C-1	B37	
i3	22	Brown	C-1	B38	
i4	20	Blue	C-2	B39	
i5	15	Gray	C-1		F/B
i6	10	*	C-1		Remote control rearview mirror switch
i7	6	Yellow	B-2		Front fog light switch
i8	4	Brown	B-2		Security indicator light
i9	6	*	B-2		TCS off switch
i10	16	Light gray	B-2		Combination meter
i11	5	Light blue	B-2		
i12	16	Light gray	B-2		Combination meter
i14	13	*	B-2		Combination meter
i15	6	*	B-3		Fan switch
i16	3	*	B-3		A/C switch
i17	16	*	B-3		Mode control panel
i18	6	*	B-3		Rear defogger switch
i19	6	Brown	B-2		Cruise control main switch
i20	4	Blue	B-3	B80	Bulkhead wiring harness
i21	2	Black	C-3		Ash tray illumination light
i22	10	*	B-3		Hazard switch
i23	2	Brown	B-4		Glove box illumination light
i24	1	*	C-3		Front accessory power supply
i25	3	*	C-3		
i26	14	*	B-3		Radio
i27	2	*	B-3		CD player illumination light
i28	1	Black	C-3		Ground
i29	1	Black	C-3		Ground (Radio)
i37	4	*	C-1		Rear defogger timer

\*: Non-colored

# WIRING DIAGRAM

[D8F1] 6-3

## 8. Electrical Wiring Harness and Ground Point



## 6-3 [D8F2]

## WIRING DIAGRAM

### 8. Electrical Wiring Harness and Ground Point


#### 2. RHD MODEL

Connector				Connecting to	
No.	Pole	Color	Area	No.	Name
i1	22	Black	C-4	B36	Bulkhead wiring harness
i2	22	*	C-4	B37	
i3	22	Brown	C-4	B38	
i4	20	Blue	C-4	B39	
i5	15	Gray	C-4		F/B
i6	10	*	C-4		Remote control rearview mirror switch
i10	16	Light gray	B-3		Combination meter
i11	5	Light blue	B-3		
i12	16	Light gray	B-3		Combination meter
i14	13	*	B-3		Combination meter
i15	8	*	B-2		Fan switch
i17	16	Black	B-2		Mode control panel
i18	6	*	B-3		Rear defogger switch
i19	6	Brown	B-3		Cruise control main switch
i20	4	Blue	B-2	B80	Bulkhead wiring harness
i22	10	*	B-2		Hazard switch
i23	2	Brown	B-2		Glove box illumination light
i24	1	*	C-2		Front accessory power supply
i25	3	*	C-2		
i26	14	*	B-2		Radio
i27	2	*	B-2		CD player illumination light
i28	1	Black	C-2		Ground
i29	1	Black	C-2		Ground (Radio)
i37	4	*	C-4		Rear defogger timer
Non-colored					

# WIRING DIAGRAM

[D8F2] 6-3

## 8. Electrical Wiring Harness and Ground Point



## G: REAR WIRING HARNESS

## 1. LHD MODEL


Connector				Connecting to	
No.	Pole	Color	Area	No.	Name
R1	8	*	B-2	B97	Bulkhead wiring harness
R2	24	Black	B-2	B98	Bulkhead wiring harness (2200 cc engine AWD except Taiwan model)
	20	*	B-2	B98	Bulkhead wiring harness (Other models)
R3	24	*	B-2	B99	Bulkhead wiring harness
R4	1	Black	B-2		Parking brake switch
R5	2	*	C-2		Select lever illumination light (AT)
R6	2	Black	C-2		Shift lock solenoid (AT)
R7	2	*	C-2		P position switch (AT)
R8	2	*	C-3		Seat belt switch
R9	1	Brown	C-4		Front door switch LH
R10	2	*	C-4	D22	Rear door cord LH (Security)
R11	8	*	C-4	D21	Rear door cord LH
R12	1	Brown	B-2		Front door switch RH
R13	2	*	B-2	D28	Rear door cord RH (Security)
R14	8	*	B-2	D27	Rear door cord RH
R15	8	*	B-3	R57	Fuel tank cord (Except Taiwan model)
	6	Black	B-3	R57	Fuel tank cord (Taiwan model)
R16	1	Brown	B-3		Rear door switch RH
R29	3	*	C-2		Diode (Security)
R30	2	Black	C-2		Diode (Rear gate latch switch) (Wagon)
R31	3	*	C-2		Diode (Security)
R41	4	Blue	B-2		Seat heater (Passenger)
R42	6	*	B-3		Seat heater switch (Passenger)
R43	6	Blue	B-3		Seat heater switch (Driver)
R44	4	Blue	C-3		Seat heater (Driver)
R46	2	*	B-3	R67	Fuel tank cord (Except Taiwan model)
R47	3	*	B-4		Fuel tank pressure sensor (2200 cc engine AWD model)
R50	4	*	B-2	B90	Bulkhead wiring harness
R51	2	*	B-2		Vanity mirror illumination light RH
R52	2	*	A-3		Room light
R53	4	*	C-3	B45	Bulkhead wiring harness
R54	2	*	B-3		Vanity mirror illumination light LH
R55	1	*	B-3		Sunroof control module (Except OUTBACK)
R56	2	*	B-3		Spot light
R57	8	*	B-3	R15	Rear wiring harness (Except Taiwan model)
	6	Black	B-3	R15	Rear wiring harness (Taiwan model)
R58	6	*	B-3		Fuel gauge module & fuel pump
R59	2	*	B-4		Fuel gauge sub module (AWD)
R67	2	*	B-3	R46	Rear wiring harness (Except Taiwan model)
R68	2	*	B-3		Pressure control solenoid valve
R69	2	*	B-3		Vent control solenoid valve
R83	4	*	B-3	R84	Fuel tank cord (2200 cc engine AWD model)
R84	4	*	B-3	R83	Rear wiring harness (2200 cc engine AWD model)
R85	3	*	B-2	B178	Bulkhead wiring harness (Wiper deicer)
R86	8	*	B-3		Wiper deicer switch
R87	4	Blue	C-3		Wiper deicer relay
R88	4	*	C-3		Wiper deicer timer
R89	6	Black	A-3		Sunroof control module (OUTBACK)
R90	6	Brown	A-3		Sunroof switch (OUTBACK)

\*: Non-colored

# WIRING DIAGRAM

[D8G1] 6-3

## 8. Electrical Wiring Harness and Ground Point





## 6-3 [D8G2]

## WIRING DIAGRAM

### 8. Electrical Wiring Harness and Ground Point

#### 2. RHD MODEL


Connector				Connecting to	
No.	Pole	Color	Area	No.	Name
R1	56	*	B-2	B97	Bulkhead wiring harness (S.M.J.)
R4	1	Black	B-2		Parking brake switch
R5	2	*	B-2		Select lever illumination light
R6	2	Black	B-2		Shift lock solenoid
R7	2	*	B-2		P position switch
R8	2	*	B-2		Seat belt switch
R9	1	Brown	B-3		Front door switch LH
R11	8	*	B-4	D21	Rear door cord LH
R12	1	Brown	B-2		Front door switch RH
R14	8	*	B-2	D27	Rear door cord RH
R15	8	*	B-3	R57	Fuel tank cord
R16	1	Brown	A-3		Rear door switch RH
R30	2	Black	B-2		Diode (Rear gate latch switch)
R46	2	*	B-3	R67	Fuel tank cord
R47	3	*	B-4		Fuel tank pressure sensor
R50	2	Green	B-2	B90	Bulkhead wiring harness
R52	2	*	A-3		Room light
R57	8	*	B-3	R15	Rear wiring harness
R58	6	*	A-3		Fuel gauge module & fuel pump
R59	2	*	B-4		Fuel gauge sub module
R67	2	*	B-3	R46	Rear wiring harness
R68	2	*	B-3		Pressure control solenoid valve
R69	2	*	A-3		Vent control solenoid valve
R83	4	*	B-3	R84	Fuel tank cord
R84	4	*	B-3	R83	Rear wiring harness

\*: Non-colored

# WIRING DIAGRAM

[D8G2] 6-3

## 8. Electrical Wiring Harness and Ground Point



## H: FLOOR WIRING HARNESS AND DOOR CORD

## 1. LHD MODEL

Connector				Connecting to	
No.	Pole	Color	Area	No.	Name
P1	20	Blue	B-1	F1	Front wiring harness (With TCS model)
	8	*	B-1	F1	Front wiring harness (With ABS model)
P2	2	Black	C-2		Diode (TCS)
P4	6	*	B-3	ABS/TCS control module	
P5	8	*	B-3		
P6	16	*	B-3		
P7	20	*	B-3		
P8	2	Gray	B-3		
	2	*	B-3		Rear ABS sensor RH (Outback with step roof)
P9	2	Gray	B-4		Rear ABS sensor LH
	2	*	B-4		Rear ABS sensor LH (Outback with step roof)
P10	40	Gray	B-2	B63	Bulkhead wiring harness (With TCS model)
P11	3	*	B-2		ABS G sensor

\*: Non-colored

Connector				Connecting to	
No.	Pole	Color	Area	No.	Name
D1	24	*	C-3	B30	Bulkhead wiring harness
D2	2	*	C-3		Front door speaker LH
D3	2	Green	C-3		Front power window motor LH
D4	2	Black	B-3		Front tweeter LH
D5	6	*	B-3		Remote control rear-view mirror LH
D6	2	*	B-3		Mirror heater LH
D7	14	*	B-3		Power window main switch
D8	4	*	B-3		Front door lock actuator LH
	4	Gray	B-3		Front door lock actuator LH (With security system)
D9	4	Gray	B-3		Front door key switch LH (Security)
D10	2	Black	C-3		Step light LH
D11	24	*	B-2	B101	Bulkhead wiring harness
D12	2	*	B-2		Front door speaker RH


Connector				Connecting to	
No.	Pole	Color	Area	No.	Name
D13	2	Green	B-2		Front power window motor RH
D14	2	Black	B-2		Front tweeter RH
D15	6	*	B-2		Remote control rear-view mirror RH
D16	2	*	B-2		Mirror heater RH
D17	5	*	B-2		Front power window sub switch RH
D18	4	*	B-2		Front door lock actuator RH
	4	Gray	B-2		Front door lock actuator RH (With security system)
D19	4	Gray	B-2		Front door key switch RH (Security)
D20	2	Black	B-2		Step light RH
D21	8	*	B-3	R11	Rear wiring harness
D22	2	*	B-3	R10	Rear wiring harness (Security)
D23	2	Black	B-4		Rear door speaker LH
D24	2	Green	B-4		Rear power window motor LH
D25	5	*	B-4		Rear power window sub switch LH
D26	4	*	B-4		Rear door lock actuator LH
	4	Gray	B-4		Rear door lock actuator LH (With security system)
D27	8	*	B-2	R14	Rear wiring harness
D28	2	*	B-2	R13	Rear wiring harness (Security)
D29	2	Black	B-2		Rear door speaker RH
D30	2	Green	B-3		Rear power window motor RH
D31	5	*	A-2		Rear power window sub switch RH
D32	4	*	A-3		Rear door lock actuator RH
	4	Gray	A-3		Rear door lock actuator RH (With security system)
D50	2	*	C-2	B113	Bulkhead wiring harness
D51	5	*	B-3		Front door lock switch LH
D52	5	*	B-2		Front door lock switch RH

\*: Non-colored

# WIRING DIAGRAM

[D8H1] 6-3

## 8. Electrical Wiring Harness and Ground Point



## 6-3 [D8H2]

## WIRING DIAGRAM

### 8. Electrical Wiring Harness and Ground Point

#### 2. RHD MODEL


Connector				Connecting to	
No.	Pole	Color	Area	No.	Name
D1	24	*	B-2	B30	Bulkhead wiring harness
D2	2	*	B-2		Front door speaker RH
D3	2	Green	B-2		Front power window motor RH
D4	2	Black	A-2		Front tweeter RH
D5	6	*	B-2		Remote control rearview mirror RH
D7	14	*	B-2		Power window main switch
D8	4	*	A-2		Front door lock actuator RH
D11	24	*	B-3	B101	Bulkhead wiring harness
D12	2	*	B-3		Front door speaker LH
D13	2	Green	B-3		Front power window motor LH
D14	2	Black	B-3		Front tweeter LH
D15	6	*	B-3		Remote control rearview mirror LH
D17	5	*	B-3		Front power window sub switch LH
D18	4	*	B-3		Front door lock actuator LH
D21	8	*	B-3	R11	Rear wiring harness
D23	2	Black	B-4		Rear door speaker LH
D24	2	Green	B-4		Rear power window motor LH
D25	5	*	B-4		Rear power window sub switch LH
D26	4	*	B-4		Rear door lock actuator LH
D27	8	*	B-2	R14	Rear wiring harness
D29	2	Black	B-3		Rear door speaker RH
D30	2	Green	A-3		Rear power window motor RH
D31	5	*	A-3		Rear power window sub switch RH
D32	4	*	A-3		Rear door lock actuator RH
D50	2	*	B-2	B113	Bulkhead wiring harness
D51	5	Green	B-2		Front door lock switch RH
D52	5	Green	C-3		Front door lock switch LH

\*: Non-colored

# WIRING DIAGRAM

[D8H2] 6-3

## 8. Electrical Wiring Harness and Ground Point



## I: REAR END WIRING HARNESS (SEDAN)


Connector				Connecting to	
No.	Pole	Color	Area	No.	Name
R17	1	Black	A-3		Rear defogger (Power)
R18	2	Black	B-3		Rear speaker RH
R19	2	*	B-3		High-mounted stop light
R20	2	Blue	B-2		Trunk room light
R21	2	Black	B-2		Rear speaker LH
R22	1	Brown	B-1		Rear door switch LH
R23	3	*	B-2		Power antenna
R24	6	*	B-3	R60	Trunk lid cord (Without security system)
	8	*	B-3	R60	Trunk lid cord (With security system)
R25	2	Black	B-4		Rear defogger condenser
R26	4	*	B-4		Rear combination light RH
R27	2	*	B-4		Trunk room light switch
R28	4	*	B-3		Rear combination light LH
R45	6	*	B-4		Trailer connector
R47	3	*	B-3		Fuel tank pressure sensor (2200 cc engine FWD and 2500 cc engine model)
R60	6	*	B-4	R24	Rear wiring harness (Without security system)
	8	*	B-4	R24	Rear wiring harness (With security system)
R61	3	*	B-4		Key switch (Security)
R62	4	*	B-4		Rear finisher light RH
R63	2	*	B-3		License plate light
R64	4	*	B-3		Rear finisher light LH
R65	1	Black	A-2		Rear defogger (Ground)
R66	2	Black	B-4		High-mounted stop light (Rear spoiler)

\*: Non-colored

# WIRING DIAGRAM

[D810] 6-3

## 8. Electrical Wiring Harness and Ground Point





**J: REAR END WIRING HARNESS (WAGON)****1. LHD MODEL**

Connector				Connecting to	
No.	Pole	Color	Area	No.	Name
R22	1	Brown	C-1		Rear door switch LH
R23	6	*	C-2		Power antenna
R25	2	Black	C-3		Rear defogger condenser
R26	4	Black	D-4		Rear combination light RH
R28	4	Black	C-2		Rear combination light LH
R32	2	*	C-2		Rear accessory power supply
R36	5	Black	C-3		Rear wiper relay
R37	2	*	C-3	D33	Rear gate cord
R38	4	*	C-3	D34	
R39	8	*	C-4	D35	
R40	4	Black	C-3	D36	Rear gate cord (With security)
R45	6	*	C-2		Trailer connector (Outback with step roof)
R47	3	*	D-3		Fuel tank pressure sensor (2200 cc engine FWD and 2500 cc engine model)
R89	8	*	D-2		Joint connector (Rear speaker)
R90	8	*	D-2		Joint connector (Rear speaker)
R91	4	Black	C-4	D65	Rear gate cord (With rear tweeter)


Connector				Connecting to	
No.	Pole	Color	Area	No.	Name
D33	2	*	C-3	R37	Rear wiring harness
D34	4	*	C-3	R38	
D35	8	*	C-4	R39	
D36	4	Black	C-3	R40	Rear wiring harness (With security)
D37	1	Black	B-3		Luggage room light
D38	1	*	B-3		
D39	2	*	B-3		High-mounted stop light
D40	1	Black	B-4		Rear defogger (Power)
D41	4	Gray	B-4		Key switch (Security)
D42	4	*	B-4		Rear finisher light RH
D43	4	*	B-3		Rear wiper motor
D44	2	*	B-4		License plate light RH
D45	2	*	A-3		License plate light LH
D46	2	Black	A-4		Rear gate latch switch
D47	4	*	A-4		Rear gate lock actuator (Without security system)
	4	Gray	A-4		Rear gate lock actuator (With security system)
D48	1	Black	B-3		Rear defogger (Ground)
D49	4	*	A-3		Rear finisher light LH
D65	4	Black	C-4	R91	Rear wiring harness (With rear tweeter)
D66	2	Black	C-3		Rear tweeter RH
D67	2	Black	B-2		Rear tweeter LH

\*: Non-colored

# WIRING DIAGRAM

[D8J1] 6-3

8. Electrical Wiring Harness and Ground Point



## 6-3 [D8J2]

## WIRING DIAGRAM

### 8. Electrical Wiring Harness and Ground Point

#### 2. RHD MODEL

Connector				Connecting to	
No.	Pole	Color	Area	No.	Name
R22	1	Brown	C-1		Rear door switch LH
R23	6	*	C-2		Power antenna
R25	2	Black	C-3		Rear defogger condenser
R26	4	Black	D-4		Rear combination light RH
R28	4	Black	C-2		Rear combination light LH
R36	5	Black	C-3		Rear wiper relay
R37	2	*	C-3	D33	Rear gate cord
R38	4	*	C-3	D34	
R39	8	*	C-4	D35	


Connector				Connecting to	
No.	Pole	Color	Area	No.	Name
D33	2	*	C-3	R37	Rear wiring harness
D34	4	*	C-3	R38	
D35	8	*	C-4	R39	
D37	1	Black	B-3		Luggage room light
D38	1	*	B-3		
D39	2	*	B-3		High-mounted stop light
D40	1	Black	B-4		Rear defogger (Power)
D42	4	*	B-4		Rear finisher light RH
D43	4	*	B-3		Rear wiper motor
D44	2	*	B-4		License plate light RH
D45	2	*	A-3		License plate light LH
D46	2	Black	A-4		Rear gate latch switch
D47	4	*	A-4		Rear gate lock actuator
D48	1	Black	B-3		Rear defogger (Ground)
D49	4	*	A-3		Rear finisher light LH

\*: Non-colored

# WIRING DIAGRAM

[D8J2] 6-3

## 8. Electrical Wiring Harness and Ground Point



MEMO: