

# SUPER MULTIPLE JUNCTION (SMJ)

Wiring System

## 3. Super Multiple Junction (SMJ) S903464


### A: HOW TO USE SUPER MULTIPLE JUNCTION (SMJ) S903464G40

The "SMJ" indicated in wiring diagrams is shown in a simplified form.


### B: TERMINAL ARRANGEMENT S903464G41

Bulkhead Wiring Harness ← → Front Wiring Harness

**B62** 66 Poles




**F45** 66 Poles




Bulkhead Wiring Harness ← → Instrument Panel Wiring Harness

**B36** 66 Poles




**i1** 66 Poles



B6M1280A

**C: INSTALLATION**

S903464A11



**Tightening torque:**


**T: 4.4 N·m (0.45 kgf·m, 3.3 ft·lb)**

**NOTE:**

- Align the cutout portion of one connector with that of other before tightening the connecting bolt.
- Do not tighten the bolt excessively since this may deform the connectors.

**D: EXPLANATION OF SMJ SHOWN IN THE WIRING DIAGRAM**

S903464G42



B6M1563A