

9. General Diagnostic S501278

A: INSPECTION S501278A10

1. SELECT LEVER DOES NOT MOVE FROM "P" POSITION S501278A1001

Symptom	Problem parts
Shift lock does not function.	<ul style="list-style-type: none"> ● Stop light switch ● Shift lock solenoid ● AT shift lock control module
Shift lock cannot be released.	<ul style="list-style-type: none"> ● Stop light switch ● Shift lock solenoid ● AT shift lock control module ● Inhibitor switch
Key interlock does not function.	<ul style="list-style-type: none"> ● Key warning switch ● "P" position switch ● Key lock solenoid ● AT shift lock control module
Key interlock cannot be released.	<ul style="list-style-type: none"> ● Key warning switch ● "P" position switch ● Key lock solenoid ● AT shift lock control module