


## 2-point type seat belts (lap only belts)

### **WARNING**

- Never use a belt that is twisted or reversed. In an accident, this can increase the risk or severity of injury.
- Keep the lap belt as low as possible on your hips. In a collision, this spreads the force of the lap belt over stronger hip bones instead of across the weaker abdomen.

The 2-point type seat belt has a manual adjustment device.


### ■ Fastening the seat belt



1. Sit well back and pick up the tongue plate marked "CENTER". Be careful not to twist the belt.
2. Insert the tongue plate into the buckle marked "CENTER" until you hear a click. If the belt is not long enough for you, hold the tongue plate at a right angle to the belt and pull the belt to extend.
3. To make the belt tight, pull up on the belt. And place the lap belt as low as possible on your hips, not on your waist.

The tongue plate marked "CENTER" can be fastened only into the buckle marked "CENTER".

## ■ Unfastening the belt



Push the button on the buckle.

When the belt is not in use, buckle the belt to prevent it from being caught in the door.

### **NOTE**

When folding down the rear seat of the wagon, store the seat belts in the seat belt pocket to prevent them falling below the cushion.

