

Diagnostics with Phenomenon

HVAC SYSTEM (AUTO A/C) (DIAGNOSTICS)

9. Diagnostics with Phenomenon

A: INSPECTION

| Symptom | Problem parts |
|---|--|
| A/C system fails to operate. | <ul style="list-style-type: none"> • Fuse (M/B No. 8, F/B No. 22, 31) • Connector (Poor contact) • Ground • Auto A/C control module • Blower fan motor • Blower fan relay • A/C relay • Compressor (Magnet clutch) • Evaporator sensor |
| Fuse is blown out. | <ul style="list-style-type: none"> • Fuse (M/B No. 8, F/B No. 22, 31) • Connector (Poor contact) |
| Illumination cannot dim. | <ul style="list-style-type: none"> • Fuse (M/B No. 8, F/B No. 22, 31) • Connector (Poor contact) • Auto A/C control module • Body integrated unit |
| Blower fan does not rotate or fan speed cannot be controlled. | <ul style="list-style-type: none"> • Fuse (F/B No. 22, 27, 28) • Connector (Poor contact) • Ground • Auto A/C control module • Blower fan motor • Blower fan relay |
| Unable to switch suction vents. | <ul style="list-style-type: none"> • Connector (Poor contact) • Auto A/C control module • Intake door actuator |
| Unable to switch vents. | <ul style="list-style-type: none"> • Connector (Poor contact) • Auto A/C control module • Mode door actuator |
| The compartment temperature does not rise. (Warm air does not come out.) | <ul style="list-style-type: none"> • Connector (Poor contact) • Auto A/C control module • Air mix door actuator • In-vehicle sensor, ambient sensor, evaporator sensor and sunload sensor • In-vehicle sensor aspirator hose |
| The compartment temperature does not lower. (Cold air does not come out.) | <ul style="list-style-type: none"> • Connector (Poor contact) • Auto A/C control module • Air mix door actuator • A/C relay • Compressor (Magnet clutch) • Radiator fan motor • Radiator fan relay • In-vehicle sensor, ambient sensor, evaporator sensor and sunload sensor • In-vehicle sensor aspirator hose |
| Compartment temperature is higher or lower than setting temperature. | <ul style="list-style-type: none"> • Auto A/C control module • Air mix door actuator • In-vehicle sensor, ambient sensor, evaporator sensor and sunload sensor • In-vehicle sensor aspirator hose |
| Compartment temperature does not quickly respond to setting temperature. | <ul style="list-style-type: none"> • Air mix door actuator • In-vehicle sensor, ambient sensor, evaporator sensor and sunload sensor • In-vehicle sensor aspirator hose |
| Radiator fan does not rotate during A/C operation. | <ul style="list-style-type: none"> • Radiator fan motor • Radiator fan relay |

Diagnostics with Phenomenon

HVAC SYSTEM (AUTO A/C) (DIAGNOSTICS)

AIRBAG SYSTEM

AB

| | Page |
|---|-------------|
| 1. General Description | 2 |
| 2. Airbag Connector | 11 |
| 3. Inspection Locations After a Collision | 14 |
| 4. Driver's Airbag Module | 17 |
| 5. Passenger's Airbag Module | 18 |
| 6. Side Airbag Module | 19 |
| 7. Curtain Airbag Module | 21 |
| 8. Airbag Control Module | 23 |
| 9. Side Airbag Sensor | 24 |
| 10. Curtain Airbag Sensor | 25 |
| 11. Roll Connector | 26 |
| 12. Front Sub Sensor | 27 |